



# SETRA CEMS™ 5.0 User Manual

Setra Systems, Inc.  
159 Swanson Road, Boxborough, MA 01719  
800.257.3872 • [www.setra.com](http://www.setra.com)



Revision	Author	Date	Notes
<b>A</b>	Samantha Shreck	February 11 <sup>th</sup> , 2022	5.0.2 version of CEMS

## Table of Contents


Table of Contents.....	3
1 Product Overview .....	6
1.1 Introduction.....	6
1.2 Additional Features .....	6
2 Setup and Activation.....	7
2.1 Sample Roadmap .....	7
3 Terminology .....	8
4 Icon Definitions.....	8
4.1 General.....	8
4.2 Menu Bar .....	9
4.3 Overall Tile.....	9
4.4 Entity.....	10
4.5 Unique .....	10
5 Home.....	11
5.1 Building Level.....	11
5.1.1 Buildings Tile.....	12
5.1.2 Monitored Spaces Tile.....	14
5.2 Monitored Space Level .....	16
5.2.1 Floor Plan View .....	16
5.2.2 Tile View .....	27
5.3 Device Level .....	27
5.3.1 Device Parameters Graph .....	28
5.3.2 Device Stacked Trend Graph .....	28
5.3.3 Edit Graphs .....	29
5.4 Alarms Tile .....	29
5.4.1 Alarm Filter .....	29
5.4.2 Details .....	30
5.4.3 Comment.....	30
5.5 Export.....	31
5.5.1 Type.....	32
5.5.2 Formats.....	32
6 Notifications.....	32

6.1	Types.....	32
6.1.1	Alarm.....	32
6.1.2	Action Level.....	32
6.1.3	Calibration .....	32
6.2	Protocols .....	32
6.3	How to Receive Notifications .....	32
6.3.1	Sign Up.....	32
6.3.2	Alarm Notification Recipients.....	33
6.4	Escalation Protocol .....	35
6.4.1	Setting up Notification Levels.....	36
6.4.2	Alarms Level Configuration.....	36
6.5	Calibration Tracking.....	38
6.5.1	Setup .....	38
6.5.2	Calibration Notification Level Configuration .....	39
6.6	Alarm Flow Chart.....	40
7	General.....	41
8	Users .....	42
8.1	Roles and Permissions .....	42
8.2	Add User .....	43
8.3	Edit User.....	44
9	Report Scheduler .....	45
9.1	List View .....	45
9.2	Calendar View .....	46
9.3	Create or delete scheduled report.....	46
9.3.1	Configuration .....	46
9.3.2	Schedule .....	47
9.4	Edit scheduled report.....	48
10	Audit Logs .....	48
10.1	Edit Time Window.....	49
10.2	Details .....	49
10.3	Comments .....	49
10.4	Sign Offs .....	49
11	Calibration Tracking Tool.....	50

11.1	View options.....	50
11.2	Export calibration report.....	51
11.3	Comments.....	51
12	Report Validator.....	51
13	Help .....	52
14	Login.....	52
15	Logout.....	52
16	Profile.....	52
17	Sample Reports .....	53
17.1	Example Report Pull.....	53
17.2	XLSX/CSV.....	56
17.3	PDF/DOCX.....	57

# 1 Product Overview

## 1.1 Introduction



The Setra CEMS is a cloud-based, real-time environmental monitoring, alarming, reporting, and data collection system for critical spaces and cleanroom environments. The system consists of a data aggregator device called SetraEDGE. This collects data from various sensors and publishes the data to Setra CEMS for further visualization, analysis, and reporting.

The core of Setra CEMS is the database managed on AWS servers. The database handles the incoming data published by SetraEDGE and passes it through the rule engine to process the data for further actions such as alarm events and historical archives. For the end-user, AWS hosts a web server that can be accessed through commonly used web browsers. Through a web browser, users can log in securely to access real-time data, configure alarm thresholds and notification protocols, and export any data timestamped and archived for up to 2 rolling years.

Setra CEMS ensures data history is backed up, recognizes alarm conditions, and can automatically send alarm notifications to individuals wherever your facility is located. This flexible and scalable system allows many configuration options. You can set up the system with multiple users of different levels of responsibility, manage multiple alarm notification methods, display data for a wide range of parameters and accommodate customer reporting requirements. You can see one location to thousands at the click of a button because of the intuitive and simple interface.


## 1.2 Additional Features

Depending on the options selected when CEMS was purchased, some features described in this User Manual may not be accessible to every user. If you would like to upgrade the feature access, please contact your Regional Sales Manager.

## 2 Setup and Activation

Each Setra CEMS monitoring system is unique. Use the sample roadmap as a guide to help identify your specific facility requirements. This will help ensure an efficient and successful activation and configuration of the Setra CEMS components.

### 2.1 Sample Roadmap







### 3 Terminology

The table below provides a list of common terminology to describe different aspects of the CEMS platform:

Terminology	Definition
<b>Customer Administrator</b>	Administrative user that is held accountable for addition/deletion of campuses, campus administrators/users and overall monitoring
<b>Campus</b>	Facility being monitored
<b>Campus Accounts</b>	All account types or user groups (administrator or user)
<b>Campus Administrator</b>	User with administrative privileges
<b>Campus User</b>	User with viewing only or restricted privileges
<b>Levels</b>	Main menus when navigating through the portal such as Building, Space, Tile View, Device View and Device Details
<b>Tiles/Tables</b>	Contained panels on the different page levels that hold a set of information such as Building Tile, Alarms Table, Device Tile, etc.
<b>Entity Types</b>	Building, Spaces, Devices
<b>Entity</b>	Single row identifying a specific item from an entity type (buildings, spaces, devices)
<b>Icon</b>	Clickable representation of an action
<b>Monitored Spaces</b>	A floor in a building
<b>Validated System</b>	Facility that needs to execute an IQOQ for validators and certification
<b>Alarm Delay</b>	Used to minimize nuisance alarms and requires the measured parameter to be beyond the Alarm threshold for the time defined by the Alarm Delay. If the user wishes to have no delay, a value of zero seconds can be used.

### 4 Icon Definitions









#### 4.1 General

Icon	Name
	Smart Building Dashboard
	Expand to Fullscreen
	Profile Settings
	Time








	Refresh
---	---------

## 4.2 Menu Bar






Icon	Name	Definition
	Home	Main dashboard features with building, monitored spaces and device details
	General	Information about CEMS software version and release
	Users	All accounts pertaining to the dashboard
	Report Scheduler	Ability to create automated reporting
	Audit Logs	Timestamped actions of all users against system
	Calibration Tracking Tool	The ability to track calibration of devices
	Report Validator	Validate reports taken off system from tampering
	Help	Information about technical support

## 4.3 Overall Tile



Icon	Name	Definition	Location
	Search	Find information	Building Tile Monitored Space Tile Report Scheduler Audit Logs
	Columns to Display	Ability to only view information that is pertinent	Building Tile Monitored Space Tile Alarms Table Device Tile
	Expand to Fullscreen	Enter Fullscreen to help visualize all data	Building Tile Map Tile Monitored Space Tile











			Alarms Table Device Tile Floorplan Tile Device Parameter Graph Stacked Trend Graph
	Edit Time Window	Adjust time window to view specific range of data	Device Parameter Graph
	Export	Generate data from the CLOUD database into a viewable document for local storage	Alarms Table Device Entity Device Parameters Graph Stacked Trend Graph Audit Logs Calibration Tracking Tool

#### 4.4 Entity

Icon	Name	Definition	Location
	Edit	Change information of an entity	Building Entity Floor Entity Device Entity
	Delete	Remove an entity	Building Entity Floor Entity Device Entity
	Alarm Notification Recipients	Register for alarms/alert notifications	Building Entity Floor Entity
	Edit Location	Adjust location of an entity	Building Entity Floor Entity Device Entity
	Navigate to Details	Proceeds to the next window	Floor Entity Device Entity

#### 4.5 Unique

Icon	Name	Definition	Location
	Alarm Filter	The ability to filter different alarm statuses to visualize different stages of notifications	Alarm Table
	Alarms Level Configuration	The ability to set escalation protocol time intervals	Building Tile

	Threshold Configuration	The ability to set low and high action levels and alarms specific to devices and their parameters	Device Tile
	Sessions	The ability to perform electronic signatures for a subset of data	Device Entity
	Details	More information on entity	Alarm Entity
	Comments	View all comments made by any user with timestamps	Alarm Entity Audit Log Entity
	Parameter Details	Enlarge parameter graph for more details	Device Parameters Graph
	Clone Device	The ability to copy device if similar information is present	Devices
	List View	Information viewed in list format	Report Scheduler
	Calendar View	Information viewed in calendar format	Report Scheduler
	Calibration Tracking Notification Configuration	The ability to set calibration notification cadence	Calibration Tracking Tool
	Halo Dot	The visualization of a device on a floor plan	Device Tile: Floor Plan View

## 5 Home

### 5.1 Building Level

The Building Level is a snapshot of any building's mapped location, floors and alarms tied to this campus.

### Buildings

Building ↑

Active Devices

Inactive Devices

Kretue Demo	0	2				
Lamorte Demo	0	2				
Setra Building	5	0				
Shreck Demo	3	0				

Items per page: 10
1 - 5 of 5

### Buildings

### Monitored Spaces

Space ↑

Clearroom				
-----------	--	--	--	--

Items per page: 10
1 - 1 of 1

### Kretue Demo: Alarms

Created ↓	Originator	Room	Level	Status	Acknowledged	Cleared
2021-04-01 13:17:19	PC5000D2	Main Room	Inactive	Active		
2021-04-01 13:14:19	FLEXD2	Main Room	Inactive	Active	✓	
2021-04-01 11:04:30	PC5000D2	Main Room	High 0.3µm Differential Action Level	Active	✓	

Items per page: 10
1 - 3 of 3

## 5.1.1 Buildings Tile

This is a list of existing buildings associated with this campus.

## Buildings

Building ↑

Active Devices

Inactive Devices

Kretue Demo	0	2				
Lamorte Demo	0	2				
Setra Building	5	0				
Shreck Demo	3	0				

Items per page: 10
1 - 5 of 5

### 5.1.1.1 Create or Delete Building

To create a new building click the plus icon above the building list and enter the following information:

- Building Name
- Location by Address or Latitude/Longitude

- Time zone

Add building

×

Building Name \*

Search by Address

Country

State

City

Zip Code

Street

Building Number

Search

Latitude

↕

Longitude

↕

Timezone \*

America/New York (UTC-05:00)

×

Powered by [GeoNames](#)

Cancel

Create

To delete a building click the trash icon in line with the building name. **This is permanent and not recoverable.**

#### 5.1.1.2 Edit Building

To edit a building click the pencil icon in line with the building name. The following fields can be adjusted:

- Building Name
- Location by Address or Latitude/Longitude
- Time zone

Edit building "Demo Building"

Building Name \*
Demo Building

Search by Address

Latitude

42.49179095

Longitude

-71.54287451685252

Timezone \*

America/New York (UTC-05:00)


Powered by [GeoNames](#)

Cancel

Save

### 5.1.1.3 Edit Building Location

To move the location of the building through the map feature using two ways: click the pencil to edit the building which will bring up an edit building pop-up or click the location tag to edit the building location using drag and drop from the map.



## 5.1.2 Monitored Spaces Tile

A list of the monitored spaces that contain the devices in a building.

### Monitored Spaces

Space ↑

Cleanroom

Items per page: 10

1 – 1 of 1

#### 5.1.2.1 Create or Delete Monitored Space

To create a new monitored space, click the plus icon above the monitored spaces list and enter the following information:

- Space Name
- Floor plan (image files only)

### Add space

Space Name \*

Floor plan

No floor plan

Drop a floor plan or click to select a file to upload.

Cancel

Create

The ability to delete any monitored space is done by clicking the trash icon in line with the space name. **This is permanent and not recoverable.**

#### 5.1.2.2 Edit Monitored Space

To edit a monitored space, click the pencil icon in line with the monitored space name. The following fields can be adjusted:

- Space Name
- Floor Plan

## 5.2 Monitored Space Level

The Monitored Space Level is a snapshot of a selected floor's devices, alarms, and floor plan.

The screenshot displays the 'Monitored Space Level' interface. On the left, a 'Floor plan' view shows a detailed layout of a room with various equipment labeled, including 'CO2', 'Particle Counter', 'FLEX', and 'control room'. Dimensions are provided for different sections of the room. On the right, the 'Cleanroom: Alarms' section lists four active alarms with columns for 'Created', 'Originator', 'Room', 'Level', 'Status', 'Acknowledged', and 'Cleared'. Below this, the 'Devices' section lists three devices: 'CO2', 'FLEX', and 'Particle Counter', each with a 'Name' and 'Type' column and associated action icons. A 'Tile View' button is located at the bottom right of the interface.


Created	Originator	Room	Level	Status	Acknowledged	Cleared
2021-04-21 10:56:11	4602	Cleanroom	High 0.5µm Differential Alarm	Active		
2021-04-21 10:13:00	9611062	Cleanroom	High Temperature Action Level	Active		
2021-04-21 09:23:00	9611062	Cleanroom	High ACH Action Level	Active		
2021-04-21 01:16:38	4602	Cleanroom	High 0.3µm Differential Alarm	Active		

Name	Type
CO2	Flex
FLEX	Flex
Particle Counter	Particle Counter

### 5.2.1 Floor Plan View


View the selected monitored space in Floor plan view which includes the device tile and alarm title for that specific space.






### 5.2.1.1 Floor Plan

Dynamic image of space with visual representation of devices.




### 5.2.1.1.1 Edit Device Location

1. Click the location mark icon on the top right of the floor plan.
2. Notice the Edit Device Location page populate.




3. To add a device to the floor plan, drag and drop the device location marker on the right of the page with the plus sign inside it.
  - a. Once placed in correct spot, notice a list to select the entity associated with that location. This will only show devices available not placed on floor plan yet.



- b. The marker will turn into a halo dot with the device name on top
- c. If entity is not selected from list, notice the marker will turn blue



- d. If you would like to delete a device, click on existing halo dot and a pop-up will generate with the ability to delete it



- e. Once satisfied with placements, the device placements will autosave and you can navigate back to Floor Level using the Navigation menu on top

#### 5.2.1.2 Legend

1. Notice the legend on the floor plan to help define the color representation of halo dots



2. When hovering over the legend, a tooltip will give further explanation of color representation meaning

**Inactive:** The device has not been communicating data for a user defined period of time.

**Normal:** Device parameter(s) are within user defined thresholds.

**Action:** Device parameter(s) have exceeded the user defined alert limits. Often serves as a warning to prevent action alarm.

**Alarm:** Device parameter(s) have exceeded the user defined action limits. Consider the most severe alarm.

**Calibration:** Indicates device calibration is approaching expiration or expired.

**Action:** Indicates the specific device parameter that is in alert status.

**Alarm:** Indicates the specific device parameter that is in alarm status.

### 5.2.1.3 Devices Table

A list of the devices in a monitored space.

Devices		+ 🔍 📄 🗑️					
Name ↑	Type						
AQM5000	Particle Counter	✎	⚙️	🗑️	📄	⬇️	📄
CO2	User Defined Device	✎	⚙️	🗑️	📄	⬇️	📄
Door	Flex	✎	⚙️	🗑️	📄	⬇️	📄

#### 5.2.1.3.1 Create or Delete Device

To create a new device, click the plus icon above the device list and enter the following information:

- Room Name
- Device Name
- Serial Number (unique for each device)
- Calibrated on Date
- Calibration due Date
- Device Type

Add device

Room \*

Device Name \*

0 / 30

Serial Number \*

0 / 30

📅 Calibrated on Date

📅 Calibration due Date

Device type \*

Cancel

Create

Once device type is selected, you will be able to fill in parameter details which follow:

- Parameter Type (User Defined or Pre-configured depending on device)
- Parameter Name (User defined or pre-defined depending on device type selected)
- Decimal Place
- Unit

You can only add up to 25 parameters per device.

**Add device** [X]

Room

Device Name \* 0 / 30

Serial Number \* 0 / 30

Calibrated on Date Calibration due Date

Device type \*  
User Defined Device

Parameter *	Decimal Place *	
User Defined 1	0.1	[Trash Icon]

Parameter name \* 0 / 30 Unit \*

Cancel Create

The ability to delete any monitored space is done by clicking the trash icon in line with the space name. **This is permanent and not recoverable.**

#### 5.2.1.3.2 Edit Device

To edit a device, click the pencil icon in line with a device name. The following fields can be adjusted:

- Room Name
- Device Name
- Serial Number
- Calibrated on Date
- Calibration due Date
- Device Type
- Parameter Details

Edit device "264"

Room \*  
Cleanroom

Device Name \*  
264

Serial Number \*  
10214741

Calibrated on Date

Calibration due Date

Device type  
User Defined Device

Parameter \*  
User Defined 1

Decimal Place \*  
0.0001

Parameter name \*  
Pressure

Unit \*  
"WC

+

Cancel

Save

#### 5.2.1.3.3 Device Thresholds Configuration

The ability to setup device threshold levels for each parameter by clicking cog icon in line with the device name:

- Alarm delay – This is in seconds
- Alarm – Low and High
- Action Level – Low and High (this alert is a warning)

You will need to enable use of action levels if desired for site.

Device Threshold Configuration

Alarm delay, s \*

10

Low ACH alarm

3

High ACH alarm

9

Low ACH action level

4

High ACH action level

6

☒ Enable action levels

Cancel

Save

#### 5.2.1.3.4 Clone Device

The ability to clone an existing device by clicking the shadowed box icon in line of device name.

The information below is cloned:

- Room
- Device Type
- Parameter Details
- Device Threshold Configurations



Clone device "264"

Device Configuration

Device Threshold Configuration

Room \*

Cleanroom

Device Name \*

0 / 30

Serial Number \*

0 / 30

Device type

User Defined Device

Parameter \*

User Defined 1

Decimal Place \*

0.0001

Parameter name \*

Pressure

Unit \*

"WC

+

Cancel

Clone

### 5.2.1.3.5 Sessions

The ability to generate electronic signatures with timestamps for a subset of data by clicking the document icon in line with a device name.

Sessions

Status filter

All

Date from

01/14/2022

Time from

12:13 PM

Date to

01/21/2022

Time to

12:13 PM

Search

Created ↓	Date/Time Range	Session ID	Session Status	Signed by
Sessions not found				

Items per page: 5

0 of 0

|< < > >|

Create Session

Sign

Lock/Unlock Session

Export

Cancel

To add a session, click create session. A dialog will pop-up prompt for a specific range of time and time zone to verify and approve a subset of data.

Create Session

Date from

02/08/2022

Time from

04:27 PM

Date to

02/09/2022

Time to

04:27 PM

Timezone \*

America/New York (UTC-05:00)

Cancel

Apply

Once a session is created for a certain time range, a session ID is created.

Sessions

Status filter

All

Date from

02/02/2022

Time from

04:36 PM

Date to

02/09/2022

Time to

04:36 PM

Search

Created ↓	Date/Time Range	Session ID	Session Status	Signed by
<input type="checkbox"/> 2022-02-09 16:28	2022-02-08 16:27 - 2022-02-09 16:27	34a7e450-89ef-11ec-a639-cd74ccf2fe1f	unsigned	

Create Session

Sign

Lock/Unlock Session

Export

Cancel

During verification of this information for the signature, you will be prompted to give a reason for the signature. The list below are the preset reasons for the signature:

- Authored
- Approved
- Reviewed
- Authorized
- Customize reason

Sessions

Status filter

All

Date from

02/02/2022

Time from

04:36 PM

Date to

02/09/2022

Time to

04:36 PM

Search

Created	Date/Time Range	Session ID	Session Status	Signed by
<input type="checkbox"/> 2022-02-09 16:28	2022-02-08 16:27 - 2022-02-09 16:27	34a7e450-89ef-11ec-a639-cd74ccf2fe1f	signed	SAMANTHA.SHRECK@setra.com, 2022-02-09 16:38 - Approved

Create Session

Sign

Lock/Unlock Session

Export

Cancel

The session can be signed, locked/unlocked as well as exported. The session can be exported as telemetry data into either PDF or DOCX with the option to include alarm data and/or audit logs.

## 5.2.2 Tile View

View the selected monitored space in Tile view which shows all devices and parameters in an easy to see overview. This can be done by clicking the tile view button below the device list.


Overview > Setra Building - Cleanroom > Tile View			
Realtime - last 5 hours			
<div>PC 100</div> <div> <div>Cumulative (counts/m³)</div> <div>Differential (counts/m³)</div> <div>PM Count (µg/m³)</div> <div>0.3µm: 0</div> <div>0.5µm: 0</div> <div>1.0µm: 0</div> <div>2.5µm: 0</div> <div>5.0µm: 0</div> <div>10.0µm: 0</div> </div>	<div>PC 10k</div> <div> <div>Cumulative (counts/m³)</div> <div>Differential (counts/m³)</div> <div>PM Count (µg/m³)</div> <div>0.3µm: 42030</div> <div>0.5µm: 4591</div> <div>1.0µm: 0</div> <div>2.5µm: 0</div> <div>5.0µm: 0</div> <div>10.0µm: 0</div> </div>	<div>FLEX 10k_2</div> <div> <div>Temperature: 69.6 °F</div> <div>Relative Humidity: 21.8 %RH</div> <div>Temperature 2: 69.9 °F</div> <div>Relative Humidity 2: 21.9 %RH</div> </div>	<div>FLEX 10k_1</div> <div> <div>Pressure: 0.048 "WC</div> <div>Temperature: 69.9 °F</div> <div>Relative Humidity: 21.5 %RH</div> <div>Temperature 2: 69.1 °F</div> <div>Relative Humidity 2: 22.3 %RH</div> </div>
<div>FLEX 100</div> <div> <div>Temperature: 70.1 °F</div> <div>Relative Humidity: 21.4 %RH</div> <div>ACH 1: 0.2 m/sec</div> <div>ACH 2: 0.1 m/sec</div> </div>			

## 5.3 Device Level

From a monitored space level, you can click on a device from the floor plan or a device from the devices list to navigate to the device specific graphs.


### 5.3.1 Device Parameters Graph

Individual parameter graphs for a selected device are shown below which can be enlarged or exported.



### 5.3.2 Device Stacked Trend Graph

From the individual device parameters graphs, you can click the button labeled Stacked Trend Graph to navigate to it. There you can enlarge or export the data.



The ability to click on any parameter listed below the graph to disable viewing it compared to other parameters.

### 5.3.3 Edit Graphs

> FLEX 10k\_1 Details Realtime - last day

Realtime History

Last  
1 day Advanced

Data aggregation function  
Sum

Grouping interval  
5 minutes Advanced

Cancel Update

All graph types can be edited using the time window function for the viewed data:

- Real Time or History
- Data Aggregation Function: Min, Max, Average, Sum, Count, None
- Grouping Interval: Clustering data into intervals for easier viewing

Another feature is click and drag on any graph to zoom into a specific period and see that subset of data.

## 5.4 Alarms Tile

Alarms tile shows all alarms in a selected building or a selected monitored space.

### 5.4.1 Alarm Filter

Created ↓	Device Name	Room	Level	Status	Acknowledged
2022-01-20 12:10:19	PC 10k	Cleanroom 100	Inactive	Active	
2022-01-20 12:07:19	PC 100	Class 10k	Inactive	Active	
2022-01-19 10:55:19	PC 10k	Cleanroom 100	Inactive	Cleared	2022-01-20 09:04:20
2022-01-19 10:52:19	PC 100	Class 10k	Inactive	Cleared	2022-01-20 09:04:20

Setra Building: Alarms

Alarm Status Filter

- ☒ Active
- ☒ Cleared

Acknowledged Status Filter

- ☐ Acknowledged
- ☒ Unacknowledged

The ability to view select alarms states and acknowledge status on the alarm tiles by clicking the filter icon:

- Alarm Status: Active or Cleared
- Acknowledge Status: Acknowledged or Unacknowledged

### 5.4.2 Details

Clicking the three horizontal dots icon will bring up the alarm details. This gives you a better look into the data recorded and what triggered the notification such as created time, originator, severity, and more.

Alarm details

Created time

2022-01-03 13:43:19

Originator

P53121217

Start time

2022-01-03 13:43:19

End time

2022-01-03 13:43:19

Type

Inactivity alarm

Severity

Critical

Status

Active Unacknowledged

Details

1 {

2 "deviceName": "P53121217",

3 "deviceLabel": "SPM",

4 "buildingLabel": "Setra - Demo Building",

5 "floorLabel": "Setra - Demo Space",

6 "roomLabel": "Cleanroom",

7 "customerLabel": "Setra Sandbox",

8 "inactivityTimeout": 1800,

9 "inactivityTimeoutLabel": "30 minutes ",

10 "alarmLabel": "Inactive",

11 "level": "level5"

Close

### 5.4.3 Comment

A comment can be added by clicking the Comment icon in line with the alarm line item. This enables the user to enter text in the comment. It also enables the user to acknowledge the alarm or implement an action on the system in response to the alarm.

The details of the comment will be recorded and included in the reports (comment text, user's name, time, and date).

Comments

2022-02-09 16:43

"Acknowledged" comment by Samantha Shreck(SAMANTHA.SHRECK@setra.com):

System powered down

Comment \*

0 / 500

Cancel

Add

In addition, when a notification is acknowledged, the required comment is also recorded for reporting and viewing. You have up to 3 comments to make.

## 5.5 Export

Anywhere in Setra CEMS you see the downward arrow icon, you can export that data in certain formats, in any defined time zone and custom time frame.

Data export

Export format \*

XLSX

Timezone \*

America/New York (UTC-05:00)

☒ Last time-interval

Last

5 hours

Advanced

☐ Time period

Cancel

Export

### 5.5.1 Type

Setra CEMS can export

- Telemetry Data
- Alarm
- Audit Logs
- Calibration Tracking Report

### 5.5.2 Formats

Reports can be generated into different formats depending on the data type selected:

Format	Data Type
<b>XLSX/CSV</b>	Telemetry Data (can include Audit Logs/Alarms) in spreadsheet view Alarms Audit Logs
<b>PDF/DOCX</b>	Telemetry Data (can include Audit Logs/Alarms) in graphical view Alarms Audit Logs

## 6 Notifications

### 6.1 Types

#### 6.1.1 Alarm

Device parameter(s) have exceeded the user defined alarm threshold limits. This is the most severe alarm.

#### 6.1.2 Action Level

Device parameter(s) have exceeded the user defined action level threshold limits. This serves as a warning to prevent and act against changes in environmental conditions.

#### 6.1.3 Calibration

This indicates calibration of a device is approaching expiration or has expired.

### 6.2 Protocols

You may receive an alarm, action level or calibration notification in a variety of ways, depending on how the campus users and administrators have configured their accounts:

- **Email:** Receive notifications when an alarm condition is present according to the device threshold configurations
- **SMS:** Receive notifications from a preset list of SMS gateways when an alarm condition is present according to the device threshold configurations

### 6.3 How to Receive Notifications

#### 6.3.1 Sign Up

Under Users Menu, with any new or existing accounts, you can sign up for different types of alarms as well as notification types (email and/or SMS).



Add User

Email \*

First Name

Last Name

Select SMS gateway

Phone

Notifications:

☒ Send email alarm notification

☐ Send SMS alarm notification

☐ Send email action level notification

☐ Send SMS action level notification

☐ Send email calibration notification

☐ Send SMS calibration notification

Select notification level \*

Level 1

Select user group \*

Activation method

Send activation email

Cancel

Create

### 6.3.2 Alarm Notification Recipients

For any building entity or monitored space entity, there is a bell icon. This is the Alarm Notification Recipients tool.

## Building List

+
⚙️
🔍
☰
🗨️

Name ↑

Active Devices

Inactive Devices ↑

Demo Building	0	9	✎️ 📍 🗑️ 🔔
---------------	---	---	-----------

## Monitored Spaces

+
🔍
☰
🗨️

Space ↑

Cleanroom Demo

▶️ ✎️ 🗑️ 🔔

Convention Demo

▶️ ✎️ 🗑️ 🔔

Items per page: 10 ▼

1 – 2 of 2

|<
<
>
>|

With scalability and multiple site locations in mind, staff that works in certain buildings or specific spaces can register to that specific area. You will only receive alarms when registered for a building or space. If a user is registered to receive alarm notification for a building, that user will receive notifications for any alarms in all the Monitored Spaces associated with that building.

Alarm Notification Recipients			
Users ↑	First name	Last name	
SAMANTHA.SHRECK@setra.com	Samantha	Shreck	
<div>Items per page: 20 1 – 1 of 1</div>			

To add an account to that area, notice the plus icon. Once clicked, the below pop-up dialog will display that contains a drop-down menu of all campus accounts.

Add User

User \*

Cancel

Create

Keep in mind that if you register for a building, you will receive all notifications for that building which includes all monitored spaces within. However, if you register for a specific monitored space, you will only receive alarms for that space.

## 6.4 Escalation Protocol

Alarm Escalation Protocol gives you the option to stagger alarm notifications to your staff depending on standard workflow procedures. It is like an army or a line of defense. Level 1 are the first responders. The first to act. Level 5 would be the highest level (e.g., general) who isn't likely involved with the space on a day to day. Below is an example of how alarm level notifications work.



### 6.4.1 Setting up Notification Levels

Under Users Menu, with any new or existing accounts, you can select which notification level you want to be. There are up to 5 levels to choose from. The default level is 1. The levels are designated for the entire dashboard.

Edit User Details

Email \*

PATRICK.MCGEE@setra.com

First Name

Patrick

Last Name

McGee

Select SMS gateway

Phone

Notifications:

☒ Send email alarm notification

☐ Send SMS alarm notification

☐ Send email action level notification

☐ Send SMS action level notification

Level 1

Level 2

Level 3

Level 4










Level 5

Cancel

Save

### 6.4.2 Alarms Level Configuration

On Building Tile, there is a cog icon. This is the Alarm Level Configuration tool.

Building List			    			
Name ↑	Active Devices	Inactive Devices				
Demo Building	0	9	   			

Once clicked, the below pop-up dialog will display. This is the time delay between the escalation levels.

By default, no interval times have been entered. **Until intervals are setup, this feature will not work.**

Alarm Levels Config

×

Alarm level 1 (min)

Alarm level 2 (min)

Alarm level 3 (min)

Alarm level 4 (min)


Alarm level 5 (min)

Cancel

Save

## 6.5 Calibration Tracking

Calibration Tracking gives you the option to stagger multiple notifications to your staff before calibration expiration of a device. Below is an example of how calibration notification levels work.



### 6.5.1 Setup

For each device on the device tile under a monitored space level, click the pencil icon for the individual entity which edits the device.

From there, you can add a calibration start date and calibration due date. Once entered, this information will feed into the calibration tracking to and if signed up for these types of notifications, will receive them accordingly.

Edit device "FLEX"

Room \*  
Cleanroom

Device Name \*  
FLEX

Serial Number \*  
9611062

Calibrated on Date \*  
11/01/2021

Calibration due Date \*  
11/01/2022

Device type  
Flex

Parameter \*  
ACH

Decimal Place \*  
1

+

Parameter \*  
Pressure

Decimal Place \*  
0.0001

Unit of Measure \*  
Manual

Unit \*  
"WC

Cancel
Save

## 6.5.2 Calibration Notification Level Configuration

Under Calibration tracking tool, there is a pie graph icon. Once clicked, the below pop-up dialog will display with the default values. You can enter in your own set intervals.

Calibration Tracking Notification Config

×

Enter number of days upon which user will be notified before expiration.

First Notification Level

30

⬆⬇⬆

Second Notification Level

20

⬆⬇⬆

Third Notification Level

10

⬆⬇⬆

Fourth Notification Level

1

⬆⬇⬆

Cancel

Save

## 6.6 Alarm Flow Chart

The following is an example of how action levels and alarm events will perform based on the following device threshold configurations:

Example Device Threshold Configuration			
<b>Alarm Delay (in seconds)</b>		10	
<b>Low Alarm</b>	20	<b>High Alarm</b>	90
<b>Low Action Level</b>	30	<b>High Action Level</b>	80

\*All configured device thresholds will be immediately added to the graphical view for both stacked trend and device parameter graphs.





## 7 General

This menu includes:

- CEMS Version
- Last Updated
- Release Notes for Current Version
- Date IQOQ Performed (editable field for your input)

## 8 Users

Only campus administrators can add or edit users.

Users Management					
Users					
Email ↑	First name	Last name	Level notification	Role	SMS gateway
PATRICK.MCGEE@setra.com	Patrick	McGee	Level 2	Administrators	
SAMANTHA.SHRECK@setra.com	Samantha	Shreck	Level 1	Administrators	Verizon
<div>Items per page: 10 1 – 2 of 2</div>					

### 8.1 Roles and Permissions

The most basic permission level only allows for viewing the dashboard. High permission levels allow performance of different actions in the dashboard.

Role	Actions Allowed
Campus Administrator	View, create, edit, delete entities Add, edit, and give permissions to campus user roles Configure notification escalation protocols and device threshold configuration, acknowledge alarms Sign offs Generate reports for telemetry data, audit logs, alarm reports
Campus Users	View Only: Most basic role with only viewing permissions of the dashboard.  Privileged: Depending on permissions authorized by a campus administrator, can perform the following: Acknowledge alarms, generate audit logs, generate alarm reports, and generate telemetry reports

Below shows campus user privileges from the software that can be given.

Select user group \*

Campus Users

User Permissions:

☐ Acknowledge alarms

☐ Generate Audit Log

☐ Generate alarm reports

☐ Generate telemetry reports

☐ Create/Sign Sessions

## 8.2 Add User

To create a new user, click the plus icon above the user names list and enter the following information:

- Email (required)
- First and Last Name (optional)
- Phone Number and SMS Gateway (optional)
- Notifications
- Notification Level: 1 – 5 (required)
- User Group: Campus Administrator or Campus User (required)
- Activation Method: Display activation link or send activation email (required)

Add User

Email \*

First Name

Last Name

Select SMS gateway

Phone

Notifications:

☒ Send email alarm notification
☐ Send SMS alarm notification

☐ Send email action level notification
☐ Send SMS action level notification

☐ Send email calibration notification
☐ Send SMS calibration notification

Select notification level \*

Level 1

Select user group \*

Activation method

Send activation email

Cancel

Create

New users will setup their own passwords through the activation link or email. All accounts are registered with emails.

### 8.3 Edit User

To edit a user by clicking the pencil icon in line with the user's name. The following fields can be adjusted:

- Email (required)
- First and Last Name (optional)
- Phone Number and SMS Gateway (optional)
- Notifications
- Notification Level: 1 – 5 (required)
- User Group: Campus Administrator or Campus User (required)
- Activation Method: Display activation link (pop up link to finalize new account setup right there) or send activation email (email sent to new user to create finalize setup) (required)

Edit User Details

Email \*

PATRICK.MCGEE@setra.com

First Name

Patrick

Last Name

McGee

Select SMS gateway

Phone

Notifications:

☒ Send email alarm notification
☐ Send SMS alarm notification

☐ Send email action level notification
☐ Send SMS action level notification

☐ Send email calibration notification
☐ Send SMS calibration notification

Select notification level \*

Level 2

Select user group \*

Campus Administrators

Disable User Account

Resend activation

Cancel

Save

## 9 Report Scheduler

Two views are available in the report scheduler and can be selected by clicking either the List view or Calendar view icon. When a report is scheduled and configured, the report will be emailed to the user who created the scheduled report.

### 9.1 List View



- Last: Select a pre-defined time frame or customer time frame using advanced toggle switch

Create scheduler event

×

Name \*

Configuration

Schedule

Report type \*

▼

Entity type

▼

Timezone \*

America/New York (UTC-05:00)

×

Last

5 hours

▼

Advanced

☐

Cancel

Create

Depending on entity type, the report format can be restricted. Follow table below for more information.

Entity Type	Report Type	Ability to Include	Report Format
<b>Building</b>	Alarms		XLSX, CSV
	Telemetry	Alarms Data, Audit Logs	ZIP (PDF,DOCX)
<b>Space</b>	Alarms		XLSX, CSV
	Telemetry	Alarms Data, Audit Logs	
<b>Device</b>	Telemetry		XLSX, CSV, DOCX, PDF

### 9.3.2 Schedule

Information required to add:

- Time zone
- Start Time
- Repeat (optional)
  - Repeats: Daily, Weekly, Monthly, Yearly, Custom Timer-based
  - Ends on

Create scheduler event

Name \*

Configuration

Schedule

Timezone \*

America/New York (UTC-05:00)

Start time \*

01/21/2022, 12:00 AM

☒ Repeat

Repeats \*

Daily

Ends on \*

01/26/2022

Cancel

Create

Any new scheduled report will take into effect the following day.

## 9.4 Edit scheduled report

Any edits to scheduled reports will be initiated and shown in the next report run.

## 10 Audit Logs

Under Audit logs, you can see all actions of users in the system such as logins and log outs, reports generated, alarm acknowledgement, and the creation, modification, or deletion of entities.



<div> <div>🕒 last day</div> <div> <div>📄</div> <div>🔄</div> <div>🔍</div> </div> </div>							
Timestamp ↓	Entity Type	Entity Name	User	Type	Status	Comment	Details
2022-01-21 12:25:13	User	samantha.shreck@setra.com	samantha.shreck@setra.com	Signed-off	Success		...
2022-01-21 12:23:42	User	samantha.shreck@setra.com	samantha.shreck@setra.com	Login	Success		...
2022-01-21 10:52:10	User	samantha.shreck@setra.com	samantha.shreck@setra.com	Logout	Success		...
2022-01-21 10:42:28	User	patrick.mcgee@setra.com	patrick.mcgee@setra.com	Login	Success		...
2022-01-21 10:29:50	User	samantha.shreck@setra.com	samantha.shreck@setra.com	Login	Success		...
2022-01-20 16:25:54	User	patrick.mcgee@setra.com	patrick.mcgee@setra.com	Login	Success		...
2022-01-20 16:25:49	User	patrick.mcgee@setra.com	patrick.mcgee@setra.com	Login	Failure		...
2022-01-20 15:53:45	User	samantha.shreck@setra.com	samantha.shreck@setra.com	Logout	Success		...
2022-01-20 15:49:32	Asset	Demo Case #11	samantha.shreck@setra.com	Building Created	Success		...
2022-01-20 15:49:31	User	samantha.shreck@setra.com	samantha.shreck@setra.com	Signed-off	Success		...
<div>Items per page: 10 1 - 10 of 20  &lt; &lt; &gt; &gt; </div>							

## 10.1 Edit Time Window

The ability to adjust time window to view specific range of data within the audit logs by clicking the button with a clock above the audit log list.

## 10.2 Details

This gives a better look into the data recorded from the user who acted against the system such as client IP address, website browser and more.

## 10.3 Comments

Any actionable input taken in the system requires a comment and is then recorded and available to be viewed in the audit logs.

Audit log Comment

Comment

create building

Close

Additional comments can be added on the audit logs, calibration tracking tool or alarms tables where a message icon is.

## 10.4 Sign Offs

Any actionable event or input in the system requires a sign off. This is an approval step that requires that campus administrator/user password and a comment. It is then saved, recorded, and timestamped to be viewable in the audit logs.




## 11.2 Export calibration report

All information given in calibration tracking tool can be exported only into XLSX or CSV format.

## 11.3 Comments


Any comments made in the calibration tracking tool for each entity will be recorded and viewable in the software or through exported reports. You have up to 3 comments to make.



The screenshot shows a 'Comments' dialog box with a dark blue header and a close button (X) in the top right corner. The main area is white and contains a timestamp '2022-01-21 13:53' and a comment by 'Samantha Shreck(samantha.shreck@setra.com):' with the text 'Working with calibration team and their schedule'. Below this is a text input field labeled 'Comment \*' with a character count '0 / 500' and a 'Cancel' button. At the bottom right is an 'Add' button.

## 12 Report Validator

CEMS provides the ability to validate all generated reports from the CEMS platform. Validation of reports uses md5sum comparison.



The screenshot shows the 'Report Validator' interface. It has a title 'Report file' and a large dashed box containing the text 'Drop a file or click to select a file to upload.' with a close button (X) on the right. Below the box, it lists supported file types: '\*.csv, \*.xlsx, \*.docx, \*.zip or \*.pdf file with maximum size 100 MBytes'. Below this, it says 'No file selected' and features a 'VALIDATE' button.

1. Drop a file or click box to select a file to upload
  - a. If clicked, a file upload window will pop up
  - b. Select appropriate file for validation
2. Once added to software, see the name of the report as well as the validate button enabled.

Report file

Drop a file or click to select a file to upload. ✕

\*.csv, \*.xlsx, \*.docx, \*.zip or \*.pdf file with maximum size 100 MBytes

Setra\_9611062\_\_report\_2022-01-20T00\_00\_00.715-05\_00.xlsx

**VALIDATE**

3. Click validate
  - a. If report wasn't corrupted or changed, a pop-up dialog will show validation was successful.

File checksum intact. Validation Successful. Close

- b. If report was tampered with, a pop-up dialog will show validation failed.

File checksum changed. Validation failed. Close

## 13 Help

Information provided to contact software provider if experiencing issues.

## 14 Login

1. Navigate to [cems.setra-cloud.com](https://cems.setra-cloud.com)
2. Notice login page that is asking for an email and a password
3. If password is forgotten, click forgotten password
4. A Request Password Reset page will be displayed
  - a. Enter email and select Request Password Reset
  - b. An email will be sent with instructions on next steps

## 15 Logout

1. Notice on the top right corner of the page and click the 3 vertical dot icon
2. Select Logout and notice the page changes to the CEMS Login page

## 16 Profile

1. Notice on the top right corner of the page and click the 3 vertical dot icon
2. Select Profile and notice the page change to Profile
3. This page provides information about the last login performed on the current account
4. This page gives the user the ability to edit the text areas listed below:
  - a. Email
  - b. First Name

- c. Last Name
- d. Language
- e. Password
5. If Change Password is clicked, notice Change Password pop up
6. Follow the directions and either Cancel or Change Password when finished
7. If updates were made to the profile, click Save

## 17 Sample Reports

### 17.1 Example Report Pull

This example report shows how to pull a telemetry report from a specific device on the monitored space level.

1. On building overview, select a building.

The screenshot displays a web application interface for building management. It is divided into several sections:

- Building List:** A table with columns for Name, Active Devices, and Inactive Devices. It shows 'Demo Building' with 0 active and 23 inactive devices.
- Map:** A map view showing the location of the 'Demo Building' (marked with a blue pin) near 'Westward Orchard' and 'Metropolitan Center'.
- Monitored Spaces:** A table with columns for Space, Name, and a set of icons. It lists 'Cleanroom Demo' and 'Convention Demo'.
- Demo Building: Alarms:** A table showing a list of alarms. The columns are: Created, Device Name, Room, Level, Status, Acknowledged, and Cleared. The table contains 6 rows of alarm data.

2. Once a building is selected, select a monitored space. This will bring you to the monitored space level.

Floor plan

● Inactive ● Normal ● Action ● Alarm ! Calibration ⚠ Action ⚠ Alarm

Cleanroom Demo: Alarms

Created ↓	Device Name	Room	Level	Status	Acknowledged	Cleared
2022-02-09 17:59:19	SPM	Hallway	Inactive	Active		...
2022-02-09 17:59:19	PEM - Cleanroom	Cleanroom	Inactive	Active		...
2022-02-09 17:59:19	SRCH	Airlock	Inactive	Active		...
2022-02-09 17:59:19	Flex - Airlock	Airlock	Inactive	Active		...
2022-02-09 17:59:19	Flex - Gown	Gown	Inactive	Active		...
2022-02-09 17:59:19	Flex - Hallway	Hallway	Inactive	Active		...
2022-02-09 17:59:19	SRH300	Cleanroom	Inactive	Active		...
2022-02-09 17:59:19	SRH200	Airlock	Inactive	Active		...

Items per page: 10 1 - 10 of 18

Devices

Name ↑	Type	
AQM5000	Particle Counter	✎ ⚙️ 🗑️ 📄 ⬇️ 📄
CO2	User Defined Device	✎ ⚙️ 🗑️ 📄 ⬇️ 📄
Door	Flex	✎ ⚙️ 🗑️ 📄 ⬇️ 📄
Flex - Airlock	Flex	✎ ⚙️ 🗑️ 📄 ⬇️ 📄

Tile View

3. Navigate to the devices tile.

Devices

Name ↑	Type	
AQM5000	Particle Counter	✎ ⚙️ 🗑️ 📄 ⬇️ 📄
CO2	User Defined Device	✎ ⚙️ 🗑️ 📄 ⬇️ 📄
Door	Flex	✎ ⚙️ 🗑️ 📄 ⬇️ 📄
Flex - Airlock	Flex	✎ ⚙️ 🗑️ 📄 ⬇️ 📄

4. In the same line as the device, notice a downward arrow icon. Click it to export telemetry data and notice the data export pop-up.

Data export

Export format \*

XLSX

Timezone \*

America/New York (UTC-05:00)

☒ Last time-interval

Last

5 hours

Advanced

☐ Time period

Cancel

Export

5. From there, select your desired format, time zone and time frame.
6. Once done, click export and notice the report download to your computer.

## 17.2 XLSX/CSV

Setra - Demo Building - Setra - Demo Space - FLEX Generated on 2021-11-23T00:00:00.066-05:00 Generated by Samantha Shreck (SAMANTHA.SHRECK@setra.com) Data Date/Time Start 2021-11-22T00:00:00.003-05:00 Data Date/Time End 2021-11-23T00:00:00.003-05:00												
Timestamp	Building	Space	Room	Serial Num	Device Id	Device Ty	Alarm Sta	Calibratec	Calibratio	9611062 Temperature	9611062	9611062 1
2021-11-22T23:57:43.120-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.24403381347656	°F	normal
2021-11-22T23:57:39.120-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.24403381347656	°F	normal
2021-11-22T23:57:31.119-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.24403381347656	°F	normal
2021-11-22T23:57:11.116-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.3340072631836	°F	normal
2021-11-22T23:55:55.109-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.3340072631836	°F	normal
2021-11-22T23:55:01.103-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.3340072631836	°F	normal
2021-11-22T23:54:21.099-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.3340072631836	°F	normal
2021-11-22T23:54:07.098-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.3340072631836	°F	normal
2021-11-22T23:52:35.089-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.3340072631836	°F	normal
2021-11-22T23:52:31.088-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.3340072631836	°F	normal
2021-11-22T23:51:41.084-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.35202026367188	°F	normal
2021-11-22T23:51:09.082-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.35202026367188	°F	normal
2021-11-22T23:50:37.080-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.35202026367188	°F	normal
2021-11-22T23:49:59.077-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.35202026367188	°F	normal
2021-11-22T23:49:23.074-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.35202026367188	°F	normal
2021-11-22T23:48:57.072-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.35202026367188	°F	normal
2021-11-22T23:48:21.070-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.35202026367188	°F	normal
2021-11-22T23:48:11.069-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.35202026367188	°F	normal
2021-11-22T23:47:57.068-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.35202026367188	°F	normal
2021-11-22T23:47:41.067-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.35202026367188	°F	normal
2021-11-22T23:47:15.064-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.31599426269531	°F	normal
2021-11-22T23:43:57.043-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.31599426269531	°F	normal
2021-11-22T23:43:41.042-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.31599426269531	°F	normal
2021-11-22T23:43:03.038-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.31599426269531	°F	normal
2021-11-22T23:42:33.035-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.31599426269531	°F	normal
2021-11-22T23:42:07.032-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:41:51.031-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:41:25.029-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:41:01.027-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:39:57.023-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:39:43.022-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:39:15.019-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:38:49.018-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:38:41.017-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:38:29.016-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:38:07.014-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:37:49.013-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:37:33.012-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:37:27.011-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:37:21.010-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:36:29.005-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal
2021-11-22T23:36:05.002-05:00	Setra - Demo Building	Setra - Demo Spac	Cleanroom	9611062	FLEX	Flex	normal	N/A	N/A	67.38800048828125	°F	normal



## 17.3 PDF/DOCX

