

For Immediate Release

Contact: Diane Shaughnessy
Setra Systems, Inc.
(978) 263-1400, Ext. 3601
shaugh@setra.com

**SETRA SYSTEMS INTRODUCES ITS NEW LOW COST
MODEL CTC HIGH ACCURACY CURRENT TRANSDUCER**

High Accuracy Measurement of AC Current

Boxborough, MA - Setra Systems, Inc., a leading manufacturer and designer of sensing instrumentation, introduces the CTC current transducer for precise measurement and control of AC current in a wide range of industrial, HVAC/R and instrumentation applications.

Setra's family of current transducers offers users an economical approach to monitoring AC current loads running through a cable or wire. Available in either 24 VDC loop power or self powered, the CTC has a self-gripping split core design making it easy to clamp the CTC onto existing power cables or wires.

The CTC series features three models with industry standard 0 to 5V, 0 to 10V and 4 to 20 mA outputs, each with a three position slide switch to select the most suitable range for the application. The 0 to 5 V and 4 to 20 mA output unit's offer 30/60/120 Amp selectable sensing ranges; and, the 0 to 10 V output unit offers 20/100/150 Amp selectable sensing ranges.

In addition, two optional power relay modules w/LED indicators, Model CCR-24 and CCR-12, are available for remote motor startup. Designed to be mechanically attached to the Model CTC on-site, the Model CCR relays provide a cost effective solution for switching loads without the need to mount an external relay elsewhere in the control enclosure.

The CTC Series are CE and RoHS compliant and are listed to UL Standard 508, File No.E317719 Industrial Control Equipment.

Setra Systems, Inc. is a designer, developer, and manufacturer of high accuracy electronic instrumentation, which measures pressure, humidity, current, acceleration, and weight. Setra's products are used by many process and manufacturing industries, federal agencies, and research laboratories. In addition, all of Setra's pressure, humidity, and current transducers are CE compliant.

For more information on the CTC Series or Setra's complete product line, contact Setra Systems, Inc., 159 Swanson Road, Boxborough, MA 01719; call 1-800-257-3872, fax: 978-264-0292 or e-mail: sales@setra.com. Visit Setra on the web at www.setra.com.

