Setra Easy CountTM EZ2 & EZ6 Counting Scales



The combination of high accuracy and low price make the Easy Count counting scales an exceptional value. They include features like a large, bright LED display, bidirectional RS-232 communications, rugged aluminum housing, a simple keypad and a stainless steel weighing pan.

All Easy Count scales employ Setra's proprietary, variable capacitance weight sensing technology. This technology requires fewer parts, allowing the scales to maintain a low profile and small footprint, providing you with better reliability and a lower price. The high displayed resolution of 1 part in 100,000 is your assurance that the Easy Count delivers the internal counting resolution needed to count accurately with lighter samples.

Each model is offered in capacities of 500 grams, 2 kilograms and 5 kilograms. No other counting scale is easier to use or more accurate than the Easy Count from Setra.

Features and Benefits

Accuracy monitor enables the supervisor to select special settings that check the sampling process and, if necessary, cause the scale to prompt the operator if the number of pieces used in the sample is too small.

Programmable RS-232 output with Script-Coder™ allows a custom label design to be printed to a thermal label printer.

Bidirectional data communications allow piece weights and commands to be downloaded from a computer.

Stability indicator. An 'OK' LED confirms that the scale is stable and weight measurements are accurate.

Large LED display for quick and easy reading and increased productivity.

Features

- High Accuracy & Resolution
- Menu-driven Programmability
- Plug and Play
- Auto Zero Tracking
- Selectable Display Update Speed
- Two Year Warranty

Options

- DYMO Labelwriter SE 300 Printer
- Setra 500 Barcode Scanner
- 3 Door Draftshield



EasyCount SPECIFICATIONS **INTERNAL RESOLUTION** 1 part in 500,000 **UNITS OF MEASURE** EZ6 - pounds, grams, ounces, user unit EZ2 - grams **COUNTING ACCURACY** Selectable from 95% to 99.99% **SAMPLE SIZES** 10, 25, 50, 100, user definable **COUNTING CAPACITY** 999,999 pieces **DATA COMMUNICATIONS Bidirectional RS232 BAUD RATES** 300, 600, 1200, 2400, 4800, 9600 **DISPLAY** 0.57" LED (all models) **PAN** Stainless steel **OPERATING TEMPERATURES** 40 ° to 100 °F (5 ° to 43 °C) **POWER ADAPTER** Input - 110 VAC/60 Hz Output - 7.5 VDC @ 500 ma **DIMENSIONS (2 - 5 Kg Cap.)** Platform 6.25" diameter (160 mm) **Overall** 7.5" W x 11" D x 2.5" H (360 x 395 x 145 mm) **DIMENSIONS (.5 Kg Cap.) Platform** 4.75" diameter (120.65 mm) 7.5" W x 11" D x 6" H (360 x 395 x 145 mm) **Overall SHIPPING WEIGHTS** 2 - 5 Kg Cap.: 9 lbs (4 Kg) 500 g Cap.: 11 lbs (5 Kg)

MODEL	CAPACITY	READABILITY	KEYBOARD	DRAFTSHIELD
EZ6-500	500 g (1 lb)	0.005 g (0.00001 lbs)	six key	circular glass (std.)
EZ6-2000	2 Kg (2.2 lbs)	0.02 g (0.00002 lbs)	six key	N/A
EZ6-5000	5 Kg (11 lbs)	0.05 g (0.0002 lbs)	six key	N/A
EZ2-500	500 g (1 lb)	0.005 g (0.00001 lbs)	two key	circular glass (std.)
EZ2-2000	2 Kg (2.2 lbs)	0.02 g (0.00002 lbs)	two key	N/A
EZ2-5000	5 Kg (11 lbs)	0.05 g (0.0002 lbs)	two key	N/A

EasyCount OPTIONS

DYMO Labelwriter Setra 300 Printer

With one of the smallest footprints of any direct thermal bar code printer, it will print up to seven Code 3 of 9 barcode fields or 23 text fields on one label. The printer is whisper quiet and accepts labels that are 2.25 inches wide by 1.25 inches or 4 inches in length. The RS232 cable to connect to the EasyCount scale is standard along with a sample roll of three hundred 4 inch labels.

Setra 400 Direct Thermal Printer

The Setra 400 printer is a high performance, direct thermal barcode printer. The printer features a positive-locking, self-aligning print head mechanism that is perfect for printing shipping labels, retail labels, package labels, and many other types and styles of labels. The printer accomodates roll-form media up to 5 inches in diameter and can be easily adjusted to work with rolls from 1 to 4 inches in width. The Setra 400 offers maximum performance at a market-leading low price.

Setra 500 Barcode Scanner

Setra's 500 barcode scanner is durable and ergonomically designed, it is the best value handheld barcode scanner in its class. The 500 has a high intensity aiming line and captures barcodes from as far away as 200 mm. The 500 is easy to aim, it scans barcodes in any lighting environment and scans virtually all 1-D bar codes. The 500 is a very rugged scanner, able to withstand drops onto concrete of up to 1.5 m (4.9 ft), designed for use in industrial environments.

3 Door Glass Draft Shield (500g cap. only)

Featuring top and side actions, and frameless design for easy access to a large chamber, measuring 7 3/16"W x 7 1/16"D x 9 13/16"H.



Setra 300 Dymo Labelwriter Printer

