

Key Features

- Simple single-room pressure indication for all pressurized spaces
- Integrated Setra Pressure transducer
- Visual alarm via red/green light ring
- Door delay
- Configurable audible alarm
- Digital display can be always-on or momentary
- Analog Output
- Easy configuration
- Sleek and attractive single wall plate
- The Setra Lite is for indoor use only.



	Standard	Dual Alert	Quick-Mount Kit
Use Case	Simple permanent monitoring of airflow	Simple permanent monitoring of air flow where status is desired in both spaces	Simple temporary monitoring of airflow
Set Up	<ul style="list-style-type: none"> • Flush mount install with 2" holesaw or in standard single gang box • Install 24VAC, 50-60Hz, 2Wmax or 24VDC (18V to 32V, 2Wmax) wiring 	<ul style="list-style-type: none"> • Flush mount install with 2" holesaw or in (2) standard single gang boxes OR • Flush mount install in place of previous thru wall monitor • Apply 24VAC, 50-60Hz, 2Wmax or 24VDC (18V to 32V, 2Wmax) wiring 	<ul style="list-style-type: none"> • Quick-mount on a simple hook or screw • Apply 24VAC, 50-60Hz, 2Wmax or 24VDC (18V to 32V, 2Wmax) via wiring or portable power supply
Kit Includes	<ul style="list-style-type: none"> • Setra Lite Base Unit - Specified by customer • Pressure Pickup Port (Setra RPS) • Mounting Hardware • Elbow Connectors 	<ul style="list-style-type: none"> • Setra Lite Base Unit - Specified by customer • LED alarm indicator with 30" cable • Pressure Pickup Port (Matching Dual Alert Variant) • 30" of rubber connecting tubing • Mounting Hardware • Elbow Connectors 	<ul style="list-style-type: none"> • Setra Lite Base Unit - Specified by customer • Pressure Pickup Port (Setra RPS) • Battery Pack • AC Adapter with 6-foot cord • Mounting bracket
Mounting	<ul style="list-style-type: none"> • Single-gang US electrical box, China 86 box, European back box, or equivalent interior dimensions • Direct to wall 	<ul style="list-style-type: none"> • Single-gang US electrical box, China 86 box, European back box, or equivalent interior dimensions • Direct to wall 	<ul style="list-style-type: none"> • Temporary mounting plate with single clearance hole
Sample Part Number	LITE050LBDWPVSAN	LITE050LBDWPVSAD	LITE050LBDWPV SAM



	Dual Rear Ports	Flush Mount Kit	Surface Mount Kit	Portable Kit
Use Case	Simple permanent monitoring of airflow relative to two remote locations	Simple permanent monitoring of airflow where other DP sensors were previously mounted	Simple permanent monitoring of airflow where large-hole drilling into wall is not feasible	Simple portable monitoring of airflow
Set Up	<ul style="list-style-type: none"> • Flush mount install with 2" holesaw or in standard single gang box • Install wiring • 24VAC, 50-60Hz, 2Wmax or VDC (18V to 32V, 2Wmax) 	<ul style="list-style-type: none"> • Flush mount install in place of previous thru wall monitor • Install wiring • 24VAC, 50-60Hz, 2Wmax or VDC (18V to 32V, 2Wmax) 	<ul style="list-style-type: none"> • Install on wall with included hardware or concrete screws • Install wiring • 24VAC, 50-60Hz, 2Wmax or VDC (18V to 32V, 2Wmax) 	<ul style="list-style-type: none"> • Carry to location for spot-checks of pressurized areas • Apply wiring from battery pack • VDC (18V to 32V, 2Wmax)
Kit Includes	<ul style="list-style-type: none"> • Setra Lite Base Unit with 2 Rear Ports - Specified by customer • 2 Pressure Pickup Ports (Setra RPS) • Mounting Hardware • Elbow connectors 	<ul style="list-style-type: none"> • Setra Lite Base Unit - Specified by customer • Pressure Pickup Port (Setra RPS) • Mounting Hardware • Elbow connectors 	<ul style="list-style-type: none"> • Setra Lite Base Unit - Specified by customer • Pressure Pickup Port (Setra RPS) • Mounting Hardware • Elbow and tubing connectors 	<ul style="list-style-type: none"> • Setra Lite Base Unit - Specified by customer • Pressure Pickup Port (Setra RPS) • Extended tubing and pressure snubber
Mounting	<ul style="list-style-type: none"> • Single-gang US electrical box, China 86 box, European back box, or equivalent interior dimensions • Direct to wall 	<ul style="list-style-type: none"> • Direct to wall or sheet metal panel 	<ul style="list-style-type: none"> • Direct to wall 	<ul style="list-style-type: none"> • None
Sample Part Number	LITDR25WBDWLASAN	LITER25WBDBLASAF	LITDR25WBDWLASAS	LITDR25WBDWPASAP
Additional Ordering Details:	To order Quick-mount Kit without the base unit, use part number 229451. To order Dual Alert Kit without the base unit, use part number 380302. To order Portable Kit without the base unit, use part number 229452. To order Surface Mount Kit without the base unit, use part number 380264. To order Flush Mount Kit without the base unit, use part number 380259.		To order white replacement bezel gasket without the base unit, use part number 380203. To order black replacement bezel gasket without the base unit, use part number 380403. To order white replacement glow ring without the base unit, use part number LITELENS-WH. To order black replacement glow ring without the base unit, use part number LITELENS-BL.	

