

# Master list for Setra FLEX™ supported BACnet objects

Sl. No.	Object Type	Instances	Object Name	Object description	Options
1	Device	DEV1	Device	Description of the NG-RPM Unit	
2	Analog Input	AI1	On-Board Analog Input 1	Indicates raw voltage reading of on-board analog input 1	
3		AI2	On-Board Analog Input 2	Indicates raw voltage reading of on-board analog input 2	
4		AI3	On-Board Analog Input 3	Indicates raw voltage reading of on-board analog input 3	
5		AI4	On-Board Analog Input 4	Indicates raw voltage reading of on-board analog input 4	
6		AI5	I/O Module Analog Input 1	Indicates raw voltage reading of IO module analog input 1	
7		AI6	I/O Module Analog Input 2	Indicates raw voltage reading of IO module analog input 2	
8		AI7	I/O Module Analog Input 3	Indicates raw voltage reading of IO module analog input 3	
9		AI8	I/O Module Analog Input 4	Indicates raw voltage reading of IO module analog input 4	
10		AI9	I/O Module Analog Input 5	Indicates raw voltage reading of IO module analog input 5	
11		AI10	I/O Module Analog Input 6	Indicates raw voltage reading of IO module analog input 6	
12		AI11	I/O Module Analog Input 7	Indicates raw voltage reading of IO module analog input 7	
13		AI12	I/O Module Analog Input 8	Indicates raw voltage reading of IO module analog input 8	
14		AI13	Room 1 Pressure	Indicates Room 1 Pressure	
15		AI14	Room 1 Temperature	Indicates Room 1 Temperature	
16		AI15	Room 1 Humidity	Indicates Room 1 Humidity	
17		AI16	Room 1 ACH	Indicates Room 1 Air Changes Per Hour	
18		AI17	Room 1 User Defined 1	Indicates Room 1 User Defined Analog Input 1 Parameter	
19		AI18	Room 1 User Defined 2	Indicates Room 1 User Defined Analog Input 2 Parameter	
20		AI19	Room 2 Pressure	Indicates Room 2 Pressure	
21		AI20	Room 2 Temperature	Indicates Room 2 Temperature	
22		AI21	Room 2 Humidity	Indicates Room 2 Humidity	
23		AI22	Room 2 ACH	Indicates Room 2 Air Changes Per Hour	
24		AI23	Room 2 User Defined 1	Indicates Room 2 User Defined Analog Input 1 Parameter	
25		AI24	Room 2 User Defined 2	Indicates Room 2 User Defined Analog Input 2 Parameter	
26		AI25	Room 3 Pressure	Indicates Room 3 Pressure	
27		AI26	Room 3 Temperature	Indicates Room 3 Temperature	
28		AI27	Room 3 Humidity	Indicates Room 3 Humidity	
29		AI28	Room 3 ACH	Indicates Room 3 Air Changes Per Hour	
30		AI29	Room 3 User Defined 1	Indicates Room 3 User Defined Analog Input 1 Parameter	
31		AI30	Room 3 User Defined 2	Indicates Room 3 User Defined Analog Input 2 Parameter	
32		Analog Output	AO1	On-Board Analog Output 1	Indicates desired output of on-board analog output 1
33	AO2		I/O Module Analog Output 1	Indicates desired output of IO module analog output 1	
34	AO3		I/O Module Analog Output 2	Indicates desired output of IO module analog output 2	
35	AO4		I/O Module Analog Output 3	Indicates desired output of IO module analog output 3	
36	AO5		I/O Module Analog Output 4	Indicates desired output of IO module analog output 4	
37	Analog Value	AV1	Room 1 Pressure Low Limit - Preset A	Indicates Room 1 Lowest Pressure Limit For Alarm Preset A	
38		AV2	Room 1 Pressure High Limit - Preset A	Indicates Room 1 Highest Pressure Limit For Alarm Preset A	
39		AV3	Room 1 Pressure Low Limit - Preset B	Indicates Room 1 Lowest Pressure Limit For Alarm Preset B	
40		AV4	Room 1 Pressure High Limit - Preset B	Indicates Room 1 Highest Pressure Limit For Alarm Preset B	
41		AV5	Room 1 Pressure Deadband	Indicates Room 1 Pressure Deadband For Alarm	
42		AV6	Room 1 Pressure Time Delay	Indicates Room 1 Pressure Time Delay For Alarm	
43		AV7	Room 1 Pressure Time Delay Normal	Indicates Room 1 Pressure Time Delay Normal For Alarm	
44		AV8	Room 1 Temperature Low Limit - Preset A	Indicates Room 1 Lowest Temperature Limit For Alarm Preset A	
45		AV9	Room 1 Temperature High Limit - Preset A	Indicates Room 1 Highest Temperature Limit For Alarm Preset A	
46		AV10	Room 1 Temperature Low Limit - Preset B	Indicates Room 1 Lowest Temperature Limit For Alarm Preset B	
47		AV11	Room 1 Temperature High Limit - Preset B	Indicates Room 1 Highest Temperature Limit For Alarm Preset B	
48		AV12	Room 1 Temperature Deadband	Indicates Room 1 Temperature Deadband For Alarm	
49		AV13	Room 1 Temperature Time Delay	Indicates Room 1 Temperature Time Delay For Alarm	
50		AV14	Room 1 Temperature Time Delay Normal	Indicates Room 1 Temperature Time Delay Normal For Alarm	
51		AV15	Room 1 Humidity Low Limit - Preset A	Indicates Room 1 Lowest Humidity Limit For Alarm Preset A	
52		AV16	Room 1 Humidity High Limit - Preset A	Indicates Room 1 Highest Humidity Limit For Alarm Preset A	
53		AV17	Room 1 Humidity Low Limit - Preset B	Indicates Room 1 Lowest Humidity Limit For Alarm Preset B	
54		AV18	Room 1 Humidity High Limit - Preset B	Indicates Room 1 Highest Humidity Limit For Alarm Preset B	
55		AV19	Room 1 Humidity Deadband	Indicates Room 1 Humidity Deadband For Alarm	
56		AV20	Room 1 Humidity Time Delay	Indicates Room 1 Humidity Time Delay For Alarm	

# Master list for Setra FLEX™ supported BACnet objects

Sl. No.	Object Type	Instances	Object Name	Object description	Options
57		AV21	Room 1 Humidity Time Delay Normal	Indicates Room 1 Humidity Time Delay Normal For Alarm	
58		AV22	Room 1 ACH Low Limit - Preset A	Indicates Room 1 Lowest ACH Limit For Alarm Preset A	
59		AV23	Room 1 ACH High Limit - Preset A	Indicates Room 1 Highest ACH Limit For Alarm Preset A	
60		AV24	Room 1 ACH Low Limit - Preset B	Indicates Room 1 Lowest ACH Limit For Alarm Preset B	
61		AV25	Room 1 ACH High Limit - Preset B	Indicates Room 1 Highest ACH Limit For Alarm Preset B	
62		AV26	Room 1 ACH Deadband	Indicates Room 1 ACH Deadband For Alarm	
63		AV27	Room 1 ACH Time Delay	Indicates Room 1 ACH Time Delay For Alarm	
64		AV28	Room 1 ACH Time Delay Normal	Indicates Room 1 ACH Time Delay Normal For Alarm	
65		AV29	Room 1 User Defined 1 Low Limit - Preset A	Indicates Room 1 Lowest User Defined 1 Limit For Alarm Preset A	
66		AV30	Room 1 User Defined 1 High Limit - Preset A	Indicates Room 1 Highest User Defined 1 Limit For Alarm Preset A	
67		AV31	Room 1 User Defined 1 Low Limit - Preset B	Indicates Room 1 Lowest User Defined 1 Limit For Alarm Preset B	
68		AV32	Room 1 User Defined 1 High Limit - Preset B	Indicates Room 1 Highest User Defined 1 Limit For Alarm Preset B	
69		AV33	Room 1 User Defined 1 Deadband	Indicates Room 1 User Defined 1 Deadband For Alarm	
70		AV34	Room 1 User Defined 1 Time Delay	Indicates Room 1 User Defined 1 Time Delay For Alarm	
71		AV35	Room 1 User Defined 1 Time Delay Normal	Indicates Room 1 User Defined 1 Time Delay Normal For Alarm	
72		AV36	Room 1 User Defined 2 Low Limit - Preset A	Indicates Room 1 Lowest User Defined 2 Limit For Alarm Preset A	
73		AV37	Room 1 User Defined 2 High Limit - Preset A	Indicates Room 1 Highest User Defined 2 Limit For Alarm Preset A	
74		AV38	Room 1 User Defined 2 Low Limit - Preset B	Indicates Room 1 Lowest User Defined 2 Limit For Alarm Preset B	
75		AV39	Room 1 User Defined 2 High Limit - Preset B	Indicates Room 1 Highest User Defined 2 Limit For Alarm Preset B	
76		AV40	Room 1 User Defined 2 Deadband	Indicates Room 1 User Defined 2 Deadband For Alarm	
77		AV41	Room 1 User Defined 2 Time Delay	Indicates Room 1 User Defined 2 Time Delay For Alarm	
78		AV42	Room 1 User Defined 2 Time Delay Normal	Indicates Room 1 User Defined 2 Time Delay Normal For Alarm	
79		AV43	Room 2 Pressure Low Limit - Preset A	Indicates Room 2 Lowest Pressure Limit For Alarm Preset A	
80		AV44	Room 2 Pressure High Limit - Preset A	Indicates Room 2 Highest Pressure Limit For Alarm Preset A	
81		AV45	Room 2 Pressure Low Limit - Preset B	Indicates Room 2 Lowest Pressure Limit For Alarm Preset B	
82		AV46	Room 2 Pressure High Limit - Preset B	Indicates Room 2 Highest Pressure Limit For Alarm Preset B	
83		AV47	Room 2 Pressure Deadband	Indicates Room 2 Pressure Deadband For Alarm	
84		AV48	Room 2 Pressure Time Delay	Indicates Room 2 Pressure Time Delay For Alarm	
85		AV49	Room 2 Pressure Time Delay Normal	Indicates Room 2 Pressure Time Delay Normal For Alarm	
86		AV50	Room 2 Temperature Low Limit - Preset A	Indicates Room 2 Lowest Temperature Limit For Alarm Preset A	
87		AV51	Room 2 Temperature High Limit - Preset A	Indicates Room 2 Highest Temperature Limit For Alarm Preset A	
88		AV52	Room 2 Temperature Low Limit - Preset B	Indicates Room 2 Lowest Temperature Limit For Alarm Preset B	
89		AV53	Room 2 Temperature High Limit - Preset B	Indicates Room 2 Highest Temperature Limit For Alarm Preset B	
90		AV54	Room 2 Temperature Deadband	Indicates Room 2 Temperature Deadband For Alarm	
91		AV55	Room 2 Temperature Time Delay	Indicates Room 2 Temperature Time Delay For Alarm	
92		AV56	Room 2 Temperature Time Delay Normal	Indicates Room 2 Temperature Time Delay Normal For Alarm	
93		AV57	Room 2 Humidity Low Limit - Preset A	Indicates Room 2 Lowest Humidity Limit For Alarm Preset A	
94		AV58	Room 2 Humidity High Limit - Preset A	Indicates Room 2 Highest Humidity Limit For Alarm Preset A	

# Master list for Setra FLEX™ supported BACnet objects

Sl. No.	Object Type	Instances	Object Name	Object description	Options
95		AV59	Room 2 Humidity Low Limit - Preset B	Indicates Room 2 Lowest Humidity Limit For Alarm Preset B	
96		AV60	Room 2 Humidity High Limit - Preset B	Indicates Room 2 Highest Humidity Limit For Alarm Preset B	
97		AV61	Room 2 Humidity Deadband	Indicates Room 2 Humidity Deadband For Alarm	
98		AV62	Room 2 Humidity Time Delay	Indicates Room 2 Humidity Time Delay For Alarm	
99		AV63	Room 2 Humidity Time Delay Normal	Indicates Room 2 Humidity Time Delay Normal For Alarm	
100		AV64	Room 2 ACH Low Limit - Preset A	Indicates Room 2 Lowest ACH Limit For Alarm Preset A	
101		AV65	Room 2 ACH High Limit - Preset A	Indicates Room 2 Highest ACH Limit For Alarm Preset A	
102		AV66	Room 2 ACH Low Limit - Preset B	Indicates Room 2 Lowest ACH Limit For Alarm Preset B	
103		AV67	Room 2 ACH High Limit - Preset B	Indicates Room 2 Highest ACH Limit For Alarm Preset B	
104		AV68	Room 2 ACH Deadband	Indicates Room 2 ACH Deadband For Alarm	
105		AV69	Room 2 ACH Time Delay	Indicates Room 2 ACH Time Delay For Alarm	
106		AV70	Room 2 ACH Time Delay Normal	Indicates Room 2 ACH Time Delay Normal For Alarm	
107		AV71	Room 2 User Defined 1 Low Limit - Preset A	Indicates Room 2 Lowest User Defined 1 Limit For Alarm Preset A	
108		AV72	Room 2 User Defined 1 High Limit - Preset A	Indicates Room 2 Highest User Defined 1 Limit For Alarm Preset A	
109		AV73	Room 2 User Defined 1 Low Limit - Preset B	Indicates Room 2 Lowest User Defined 1 Limit For Alarm Preset B	
110		AV74	Room 2 User Defined 1 High Limit - Preset B	Indicates Room 2 Highest User Defined 1 Limit For Alarm Preset B	
111		AV75	Room 2 User Defined 1 Deadband	Indicates Room 2 User Defined 1 Deadband For Alarm	
112		AV76	Room 2 User Defined 1 Time Delay	Indicates Room 2 User Defined 1 Time Delay For Alarm	
113		AV77	Room 2 User Defined 1 Time Delay Normal	Indicates Room 2 User Defined 1 Time Delay Normal For Alarm	
114		AV78	Room 2 User Defined 2 Low Limit - Preset A	Indicates Room 2 Lowest User Defined 2 Limit For Alarm Preset A	
115		AV79	Room 2 User Defined 2 High Limit - Preset A	Indicates Room 2 Highest User Defined 2 Limit For Alarm Preset A	
116		AV80	Room 2 User Defined 2 Low Limit - Preset B	Indicates Room 2 Lowest User Defined 2 Limit For Alarm Preset B	
117		AV81	Room 2 User Defined 2 High Limit - Preset B	Indicates Room 2 Highest User Defined 2 Limit For Alarm Preset B	
118		AV82	Room 2 User Defined 2 Deadband	Indicates Room 2 User Defined 2 Deadband For Alarm	
119		AV83	Room 2 User Defined 2 Time Delay	Indicates Room 2 User Defined 2 Time Delay For Alarm	
120		AV84	Room 2 User Defined 2 Time Delay Normal	Indicates Room 2 User Defined 2 Time Delay Normal For Alarm	
121		AV85	Room 3 Pressure Low Limit - Preset A	Indicates Room 3 Lowest Pressure Limit For Alarm Preset A	
122		AV86	Room 3 Pressure High Limit - Preset A	Indicates Room 3 Highest Pressure Limit For Alarm Preset A	
123		AV87	Room 3 Pressure Low Limit - Preset B	Indicates Room 3 Lowest Pressure Limit For Alarm Preset B	
124		AV88	Room 3 Pressure High Limit - Preset B	Indicates Room 3 Highest Pressure Limit For Alarm Preset B	
125		AV89	Room 3 Pressure Deadband	Indicates Room 3 Pressure Deadband For Alarm	
126		AV90	Room 3 Pressure Time Delay	Indicates Room 3 Pressure Time Delay For Alarm	
127		AV91	Room 3 Pressure Time Delay Normal	Indicates Room 3 Pressure Time Delay Normal For Alarm	
128		AV92	Room 3 Temperature Low Limit - Preset A	Indicates Room 3 Lowest Temperature Limit For Alarm Preset A	
129		AV93	Room 3 Temperature High Limit - Preset A	Indicates Room 3 Highest Temperature Limit For Alarm Preset A	
130		AV94	Room 3 Temperature Low Limit - Preset B	Indicates Room 3 Lowest Temperature Limit For Alarm Preset B	
131		AV95	Room 3 Temperature High Limit - Preset B	Indicates Room 3 Highest Temperature Limit For Alarm Preset B	
132		AV96	Room 3 Temperature Deadband	Indicates Room 3 Temperature Deadband For Alarm	

# Master list for Setra FLEX™ supported BACnet objects

Sl. No.	Object Type	Instances	Object Name	Object description	Options
133	Analog Value	AV97	Room 3 Temperature Time Delay	Indicates Room 3 Temperature Time Delay For Alarm	
134		AV98	Room 3 Temperature Time Delay Normal	Indicates Room 3 Temperature Time Delay Normal For Alarm	
135		AV99	Room 3 Humidity Low Limit - Preset A	Indicates Room 3 Lowest Humidity Limit For Alarm Preset A	
136		AV100	Room 3 Humidity High Limit - Preset A	Indicates Room 3 Highest Humidity Limit For Alarm Preset A	
137		AV101	Room 3 Humidity Low Limit - Preset B	Indicates Room 3 Lowest Humidity Limit For Alarm Preset B	
138		AV102	Room 3 Humidity High Limit - Preset B	Indicates Room 3 Highest Humidity Limit For Alarm Preset B	
139		AV103	Room 3 Humidity Deadband	Indicates Room 3 Humidity Deadband For Alarm	
140		AV104	Room 3 Humidity Time Delay	Indicates Room 3 Humidity Time Delay For Alarm	
141		AV105	Room 3 Humidity Time Delay Normal	Indicates Room 3 Humidity Time Delay Normal For Alarm	
142		AV106	Room 3 ACH Low Limit - Preset A	Indicates Room 3 Lowest ACH Limit For Alarm Preset A	
143		AV107	Room 3 ACH High Limit - Preset A	Indicates Room 3 Highest ACH Limit For Alarm Preset A	
144		AV108	Room 3 ACH Low Limit - Preset B	Indicates Room 3 Lowest ACH Limit For Alarm Preset B	
145		AV109	Room 3 ACH High Limit - Preset B	Indicates Room 3 Highest ACH Limit For Alarm Preset B	
146		AV110	Room 3 ACH Deadband	Indicates Room 3 ACH Deadband For Alarm	
147		AV111	Room 3 ACH Time Delay	Indicates Room 3 ACH Time Delay For Alarm	
148		AV112	Room 3 ACH Time Delay Normal	Indicates Room 3 ACH Time Delay Normal For Alarm	
149		AV113	Room 3 User Defined 1 Low Limit - Preset A	Indicates Room 3 Lowest User Defined 1 Limit For Alarm Preset A	
150		AV114	Room 3 User Defined 1 High Limit - Preset A	Indicates Room 3 Highest User Defined 1 Limit For Alarm Preset A	
151		AV115	Room 3 User Defined 1 Low Limit - Preset B	Indicates Room 3 Lowest User Defined 1 Limit For Alarm Preset B	
152		AV116	Room 3 User Defined 1 High Limit - Preset B	Indicates Room 3 Highest User Defined 1 Limit For Alarm Preset B	
153		AV117	Room 3 User Defined 1 Deadband	Indicates Room 3 User Defined 1 Deadband For Alarm	
154		AV118	Room 3 User Defined 1 Time Delay	Indicates Room 3 User Defined 1 Time Delay For Alarm	
155		AV119	Room 3 User Defined 1 Time Delay Normal	Indicates Room 3 User Defined 1 Time Delay Normal For Alarm	
156		AV120	Room 3 User Defined 2 Low Limit - Preset A	Indicates Room 3 Lowest User Defined 2 Limit For Alarm Preset A	
157		AV121	Room 3 User Defined 2 High Limit - Preset A	Indicates Room 3 Highest User Defined 2 Limit For Alarm Preset A	
158		AV122	Room 3 User Defined 2 Low Limit - Preset B	Indicates Room 3 Lowest User Defined 2 Limit For Alarm Preset B	
159		AV123	Room 3 User Defined 2 High Limit - Preset B	Indicates Room 3 Highest User Defined 2 Limit For Alarm Preset B	
160		AV124	Room 3 User Defined 2 Deadband	Indicates Room 3 User Defined 2 Deadband For Alarm	
161		AV125	Room 3 User Defined 2 Time Delay	Indicates Room 3 User Defined 2 Time Delay For Alarm	
162		AV126	Room 3 User Defined 2 Time Delay Normal	Indicates Room 3 User Defined 2 Time Delay Normal For Alarm	
163		AV127	Room 1 Length	Indicates The Length Of Room 1	
164		AV128	Room 1 Width	Indicates The Width Of Room 1	
165		AV129	Room 1 Height	Indicates The Height Of Room 1	
166		AV130	Room 2 Length	Indicates The Length Of Room 2	
167	AV131	Room 2 Width	Indicates The Width Of Room 2		
168	AV132	Room 2 Height	Indicates The Height Of Room 2		
169	AV133	Room 3 Length	Indicates The Length Of Room 3		
170	AV134	Room 3 Width	Indicates The Width Of Room 3		
171	AV135	Room 3 Height	Indicates The Height Of Room 3		
172	AV136	Mute Time Out	Buzzer Volume Mute Timeout (Ranges from 0 to 9999). 99999 will make the Buzzer Volume Mute Forever		
173	AV137	Buzzer Volume	Buzzer volume enumeration		
174	AV138	Brightness Level	Display brightness level		
175	AV139	Home Screen Timeout	Time delay after pressing full screen where view returns to normal screen, and vice versa depending on full screen setting.		
176	AV140	Room Carousel Interval	Interval at which to toggle display of multiple rooms.		

# Master list for Setra FLEX™ supported BACnet objects

Sl. No.	Object Type	Instances	Object Name	Object description	Options
177		AV141	Room 1 Parameter 1 BACnet Device Instance	Device instance of a BACnet object associated with Room 1 parameter 1 (pressure)	
178		AV142	Room 1 Parameter 1 BACnet Object Instance	Object instance of a BACnet object associated with Room 1 parameter 1 (pressure)	
179		AV143	Room 1 Parameter 2 BACnet Device Instance	Device instance of a BACnet object associated with Room 1 parameter 2 (temperature)	
180		AV144	Room 1 Parameter 2 BACnet Object Instance	Object instance of a BACnet object associated with Room 1 parameter 2 (temperature)	
181		AV145	Room 1 Parameter 3 BACnet Device Instance	Device instance of a BACnet object associated with Room 1 parameter 3 (humidity)	
182		AV146	Room 1 Parameter 3 BACnet Object Instance	Object instance of a BACnet object associated with Room 1 parameter 3 (humidity)	
183		AV147	Room 1 Parameter 4 BACnet Device Instance	Device instance of a BACnet object associated with Room 1 parameter 4 (ACH)	
184		AV148	Room 1 Parameter 4 BACnet Object Instance	Object instance of a BACnet object associated with Room 1 parameter 4 (ACH)	
185		AV149	Room 1 Parameter 5 BACnet Device Instance	Device instance of a BACnet object associated with Room 1 parameter 5 (user defined 1)	
186		AV150	Room 1 Parameter 5 BACnet Object Instance	Object instance of a BACnet object associated with Room 1 parameter 5 (user defined 1)	
187		AV151	Room 1 Parameter 6 BACnet Device Instance	Device instance of a BACnet object associated with Room 1 parameter 6 (user defined 2)	
188		AV152	Room 1 Parameter 6 BACnet Object Instance	Object instance of a BACnet object associated with Room 1 parameter 6 (user defined 2)	
189		AV153	Room 2 Parameter 1 BACnet Device Instance	Device instance of a BACnet object associated with Room 2 parameter 1 (pressure)	
190		AV154	Room 2 Parameter 1 BACnet Object Instance	Object instance of a BACnet object associated with Room 2 parameter 1 (pressure)	
191		AV155	Room 2 Parameter 2 BACnet Device Instance	Device instance of a BACnet object associated with Room 2 parameter 2 (temperature)	
192		AV156	Room 2 Parameter 2 BACnet Object Instance	Object instance of a BACnet object associated with Room 2 parameter 2 (temperature)	
193		AV157	Room 2 Parameter 3 BACnet Device Instance	Device instance of a BACnet object associated with Room 2 parameter 3 (humidity)	
194		AV158	Room 2 Parameter 3 BACnet Object Instance	Object instance of a BACnet object associated with Room 2 parameter 3 (humidity)	
195		AV159	Room 2 Parameter 4 BACnet Device Instance	Device instance of a BACnet object associated with Room 2 parameter 4 (ACH)	
196		AV160	Room 2 Parameter 4 BACnet Object Instance	Object instance of a BACnet object associated with Room 2 parameter 4 (ACH)	
197		AV161	Room 2 Parameter 5 BACnet Device Instance	Device instance of a BACnet object associated with Room 2 parameter 5 (user defined 1)	
198		AV162	Room 2 Parameter 5 BACnet Object Instance	Object instance of a BACnet object associated with Room 2 parameter 5 (user defined 1)	
199		AV163	Room 2 Parameter 6 BACnet Device Instance	Device instance of a BACnet object associated with Room 2 parameter 6 (user defined 2)	
200		AV164	Room 2 Parameter 6 BACnet Object Instance	Object instance of a BACnet object associated with Room 2 parameter 6 (user defined 2)	
201		AV165	Room 3 Parameter 1 BACnet Device Instance	Device instance of a BACnet object associated with Room 3 parameter 1 (pressure)	
202		AV166	Room 3 Parameter 1 BACnet Object Instance	Object instance of a BACnet object associated with Room 3 parameter 1 (pressure)	
203		AV167	Room 3 Parameter 2 BACnet Device Instance	Device instance of a BACnet object associated with Room 3 parameter 2 (temperature)	
204		AV168	Room 3 Parameter 2 BACnet Object Instance	Object instance of a BACnet object associated with Room 3 parameter 2 (temperature)	
205		AV169	Room 3 Parameter 3 BACnet Device Instance	Device instance of a BACnet object associated with Room 3 parameter 3 (humidity)	
206		AV170	Room 3 Parameter 3 BACnet Object Instance	Object instance of a BACnet object associated with Room 3 parameter 3 (humidity)	
207		AV171	Room 3 Parameter 4 BACnet Device Instance	Device instance of a BACnet object associated with Room 3 parameter 4 (ACH)	
208		AV172	Room 3 Parameter 4 BACnet Object Instance	Object instance of a BACnet object associated with Room 3 parameter 4 (ACH)	
209		AV173	Room 3 Parameter 5 BACnet Device Instance	Device instance of a BACnet object associated with Room 3 parameter 5 (user defined 1)	
210		AV174	Room 3 Parameter 5 BACnet Object Instance	Object instance of a BACnet object associated with Room 3 parameter 5 (user defined 1)	
211		AV175	Room 3 Parameter 6 BACnet Device Instance	Device instance of a BACnet object associated with Room 3 parameter 6 (user defined 2)	
212		AV176	Room 3 Parameter 6 BACnet Object Instance	Object instance of a BACnet object associated with Room 3 parameter 6 (user defined 2)	
213		AV177	Control Loop 1 Setpoint Preset A	Contains the target setpoint for control loop (or external setpoint) 1 preset A	
214		AV178	Control Loop 1 Max Setpoint Preset A	Contains the maximum allowable setpoint for control loop (or external setpoint) 1 preset A	

# Master list for Setra FLEX™ supported BACnet objects

Sl. No.	Object Type	Instances	Object Name	Object description	Options
215		AV179	Control Loop 1 Min Setpoint Preset A	Contains the minimum allowable setpoint for control loop (or external setpoint) 1 preset A	
216		AV180	Control Loop 1 Setpoint Preset B	Contains the target setpoint for control loop (or external setpoint) 1 preset B	
217		AV181	Control Loop 1 Max Setpoint Preset B	Contains the maximum allowable setpoint for control loop (or external setpoint) 1 preset B	
218		AV182	Control Loop 1 Min Setpoint Preset B	Contains the minimum allowable setpoint for control loop (or external setpoint) 1 preset B	
219		AV183	External Setpoint 1 BACnet Device Instance	Contains the device instance of the external setpoint 1	
220		AV184	External Setpoint 1 BACnet Object Instance	Contains the object instance of the external setpoint 1	
221		AV185	Control Loop 2 Setpoint Preset A	Contains the target setpoint for control loop (or external setpoint) 1 preset A	
222		AV186	Control Loop 2 Max Setpoint Preset A	Contains the maximum allowable setpoint for control loop (or external setpoint) 1 preset A	
223		AV187	Control Loop 2 Min Setpoint Preset A	Contains the minimum allowable setpoint for control loop (or external setpoint) 1 preset A	
224		AV188	Control Loop 2 Setpoint Preset B	Contains the target setpoint for control loop (or external setpoint) 1 preset B	
225		AV189	Control Loop 2 Max Setpoint Preset B	Contains the maximum allowable setpoint for control loop (or external setpoint) 1 preset B	
226		AV190	Control Loop 2 Min Setpoint Preset B	Contains the minimum allowable setpoint for control loop (or external setpoint) 1 preset B	
227		AV191	External Setpoint 2 BACnet Device Instance	Contains the device instance of the external setpoint 2	
228		AV192	External Setpoint 2 BACnet Object Instance	Contains the object instance of the external setpoint 2	
229		AV193	Control Loop 3 Setpoint Preset A	Contains the target setpoint for control loop (or external setpoint) 1 preset A	
230		AV194	Control Loop 3 Max Setpoint Preset A	Contains the maximum allowable setpoint for control loop (or external setpoint) 1 preset A	
231		AV195	Control Loop 3 Min Setpoint Preset A	Contains the minimum allowable setpoint for control loop (or external setpoint) 1 preset A	
232		AV196	Control Loop 3 Setpoint Preset B	Contains the target setpoint for control loop (or external setpoint) 1 preset B	
233		AV197	Control Loop 3 Max Setpoint Preset B	Contains the maximum allowable setpoint for control loop (or external setpoint) 1 preset B	
234		AV198	Control Loop 3 Min Setpoint Preset B	Contains the minimum allowable setpoint for control loop (or external setpoint) 1 preset B	
235		AV199	External Setpoint 3 BACnet Device Instance	Contains the device instance of the external setpoint 3	
236		AV200	External Setpoint 3 BACnet Object Instance	Contains the object instance of the external setpoint 3	
237		AV201	Control Loop 4 Setpoint Preset A	Contains the target setpoint for control loop (or external setpoint) 1 preset A	
238		AV202	Control Loop 4 Max Setpoint Preset A	Contains the maximum allowable setpoint for control loop (or external setpoint) 1 preset A	
239	AV203	Control Loop 4 Min Setpoint Preset A	Contains the minimum allowable setpoint for control loop (or external setpoint) 1 preset A		
240	AV204	Control Loop 4 Setpoint Preset B	Contains the target setpoint for control loop (or external setpoint) 1 preset B		
241	AV205	Control Loop 4 Max Setpoint Preset B	Contains the maximum allowable setpoint for control loop (or external setpoint) 1 preset B		
242	AV206	Control Loop 4 Min Setpoint Preset B	Contains the minimum allowable setpoint for control loop (or external setpoint) 1 preset B		
243	AV207	External Setpoint 4 BACnet Device Instance	Contains the device instance of the external setpoint 4		
244	AV208	External Setpoint 4 BACnet Object Instance	Contains the object instance of the external setpoint 4		
245	Binary Input	BI1	On-board digital input 1 status	Indicates the present state of the on-board digital input 1 (not true dig. in)	
246		BI2	On-board digital input 2 status	Indicates the present state of the on-board digital input 2	
247		BI3	On-board digital input 3 status	Indicates the present state of the on-board digital input 3	
248		BI4	On-board digital input 4 status	Indicates the present state of the on-board digital input 4	
249		BI5	I/O Module digital input 1 status	Indicates the present state of the I/O module digital input 1	
250		BI6	I/O Module digital input 2 status	Indicates the present state of the I/O module digital input 2	
251		BI7	I/O Module digital input 3 status	Indicates the present state of the I/O module digital input 3	
252		BI8	I/O Module digital input 4 status	Indicates the present state of the I/O module digital input 4	
253		BI9	I/O Module digital input 5 status	Indicates the present state of the I/O module digital input 5	
254		BI10	I/O Module digital input 6 status	Indicates the present state of the I/O module digital input 6	
255		BI11	I/O Module digital input 7 status	Indicates the present state of the I/O module digital input 7	
256		BI12	I/O Module digital input 8 status	Indicates the present state of the I/O module digital input 8	
257		BI13	Room 1 Door Input	Indicates the present state of room 1 door input	
258		BI14	Room 2 Door Input	Indicates the present state of room 2 door input	
259		BI15	Room 3 Door Input	Indicates the present state of room 3 door input	

# Master list for Setra FLEX™ supported BACnet objects

Sl. No.	Object Type	Instances	Object Name	Object description	Options
260	Binary Output	BO1	On-board relay status	Indicates the present state of the on-board relay	
261		BO2	I/O module relay 1 status	Indicates the present state of the I/O module relay 1	
262		BO3	I/O module relay 2 status	Indicates the present state of the I/O module relay 2	
263		BO4	I/O module relay 3 status	Indicates the present state of the I/O module relay 3	
264		BO5	I/O module relay 4 status	Indicates the present state of the I/O module relay 4	
265	Binary Value †	BV1	Latch Alarm Enable	0- Disabled 1- Enabled	
266		BV2	Audible Alarm Status	0- Disabled 1- Enabled	
267		BV3	Mute Alarm Enable	0- Disabled 1- Enabled	
268		BV4	Full Screen	0- Disabled 1- Enabled	
269		BV5	Room Carousel	0- Disabled 1- Enabled	
270		BV6	Engineer Password Status	0- Disabled 1- Enabled	
271		BV7	User Password Status	0- Disabled 1- Enabled	
272		BV8	Room 1 Pressure Parameter Enabled	0- Disabled 1- Enabled	
273		BV9	Room 1 Temperature Parameter Enabled	0- Disabled 1- Enabled	
274		BV10	Room 1 Humidity Parameter Enabled	0- Disabled 1- Enabled	
275		BV11	Room 1 ACH Parameter Enabled	0- Disabled 1- Enabled	
276		BV12	Room 1 User Defined 1 Parameter Enabled	0- Disabled 1- Enabled	
277		BV13	Room 1 User Defined 2 Parameter Enabled	0- Disabled 1- Enabled	
278		BV14	Room 2 Pressure Parameter Enabled	0- Disabled 1- Enabled	
279		BV15	Room 2 Temperature Parameter Enabled	0- Disabled 1- Enabled	
280		BV16	Room 2 Humidity Parameter Enabled	0- Disabled 1- Enabled	
281		BV17	Room 2 ACH Parameter Enabled	0- Disabled 1- Enabled	
282		BV18	Room 2 User Defined 1 Parameter Enabled	0- Disabled 1- Enabled	
283		BV19	Room 2 User Defined 2 Parameter Enabled	0- Disabled 1- Enabled	
284		BV20	Room 3 Pressure Parameter Enabled	0- Disabled 1- Enabled	
285		BV21	Room 3 Temperature Parameter Enabled	0- Disabled 1- Enabled	
286		BV22	Room 3 Humidity Parameter Enabled	0- Disabled 1- Enabled	
287		BV23	Room 3 ACH Parameter Enabled	0- Disabled 1- Enabled	
288		BV24	Room 3 User Defined1 Parameter Enabled	0- Disabled 1- Enabled	
289		BV25	Room 3 User Defined 2 Parameter Enabled	0- Disabled 1- Enabled	
290		BV26	Room 1 Pressure Low Limit Enabled	0- Disabled 1- Enabled	
291		BV27	Room 1 Pressure High Limit Enabled	0- Disabled 1- Enabled	
292		BV28	Room 1 Temperature Low Limit Enabled	0- Disabled 1- Enabled	
293		BV29	Room 1 Temperature High Limit Enabled	0- Disabled 1- Enabled	
294		BV30	Room 1 Humidity Low Limit Enabled	0- Disabled 1- Enabled	
295		BV31	Room 1 Humidity High Limit Enabled	0- Disabled 1- Enabled	

# Master list for Setra FLEX™ supported BACnet objects

Sl. No.	Object Type	Instances	Object Name	Object description	Options
296		BV32	Room 1 ACH Low Limit Enabled	0- Disabled 1- Enabled	
297		BV33	Room 1 ACH High Limit Enabled	0- Disabled 1- Enabled	
298		BV34	Room 1 User Defined 1 Low Limit Enabled	0- Disabled 1- Enabled	
299		BV35	Room 1 User Defined 1 High Limit Enabled	0- Disabled 1- Enabled	
300		BV36	Room 1 User Defined 2 Low Limit Enabled	0- Disabled 1- Enabled	
301		BV37	Room 1 User Defined 2 High Limit Enabled	0- Disabled 1- Enabled	
302		BV38	Room 2 Pressure Low Limit Enabled	0- Disabled 1- Enabled	
303		BV39	Room 2 Pressure High Limit Enabled	0- Disabled 1- Enabled	
304		BV40	Room 2 Temperature Low Limit Enabled	0- Disabled 1- Enabled	
305		BV41	Room 2 Temperature High Limit Enabled	0- Disabled 1- Enabled	
306		BV42	Room 2 Humidity Low Limit Enabled	0- Disabled 1- Enabled	
307		BV43	Room 2 Humidity High Limit Enabled	0- Disabled 1- Enabled	
308		BV44	Room 2 ACH Low Limit Enabled	0- Disabled 1- Enabled	
309		BV45	Room 2 ACH High Limit Enabled	0- Disabled 1- Enabled	
310		BV46	Room 2 User Defined 1 Low Limit Enabled	0- Disabled 1- Enabled	
311		BV47	Room 2 User Defined 1 High Limit Enabled	0- Disabled 1- Enabled	
312		BV48	Room 2 User Defined 2 Low Limit Enabled	0- Disabled 1- Enabled	
313		BV49	Room 2 User Defined 2 High Limit Enabled	0- Disabled 1- Enabled	
314		BV50	Room 3 Pressure Low Limit Enabled	0- Disabled 1- Enabled	
315		BV51	Room 3 Pressure High Limit Enabled	0- Disabled 1- Enabled	
316		BV52	Room 3 Temperature Low Limit Enabled	0- Disabled 1- Enabled	
317		BV53	Room 3 Temperature High Limit Enabled	0- Disabled 1- Enabled	
318		BV54	Room 3 Humidity Low Limit Enabled	0- Disabled 1- Enabled	
319		BV55	Room 3 Humidity High Limit Enabled	0- Disabled 1- Enabled	
320		BV56	Room 3 ACH Low Limit Enabled	0- Disabled 1- Enabled	
321		BV57	Room 3 ACH High Limit Enabled	0- Disabled 1- Enabled	
322		BV58	Room 3 User Defined 1 Low Limit Enabled	0- Disabled 1- Enabled	
323		BV59	Room 3 User Defined 1 High Limit Enabled	0- Disabled 1- Enabled	
324		BV60	Room 3 User Defined 2 Low Limit Enabled	0- Disabled 1- Enabled	
325		BV61	Room 3 User Defined 2 High Limit Enabled	0- Disabled 1- Enabled	
326		BV62	Room 1 Door Enabled	0- Disabled 1- Enabled	
327		BV63	Room 2 Door Enabled	0- Disabled 1- Enabled	
328		BV64	Room 3 Door Enabled	0- Disabled 1- Enabled	
329		BV65	Room 1 Enable	0- Disabled 1- Enabled	
330		BV66	Room 2 Enable	0- Disabled 1- Enabled	
331		BV67	Room 3 Enable	0- Disabled 1- Enabled	
332		BV68	Room Profile 1 - Alarm Enable	0- Disabled 1- Enabled	
333		BV69	Room Profile 2 - Alarm Enable	0- Disabled 1- Enabled	



# Master list for Setra FLEX™ supported BACnet objects

Sl. No.	Object Type	Instances	Object Name	Object description	Options
334		BV70	Room Profile 3 - Alarm Enable	0- Disabled 1- Enabled	
335		BV71	Room Profile 4 - Alarm Enable	0- Disabled 1- Enabled	
336		BV72	Room 1 in standby	0- not in standby 1- in standby	
337		BV73	Room 2 in standby	0- not in standby 1- in standby	
338		BV74	Room 3 in standby	0- not in standby 1- in standby	
339		BV75	Room 1 Pressure Mode	0 - POSITIVE 1 - NEGATIVE	
340		BV76	Room 2 Pressure Mode	0 - POSITIVE 1 - NEGATIVE	
341		BV77	Room 3 Pressure Mode	0 - POSITIVE 1 - NEGATIVE	
342		BV78	Control Loop 1 Setpoint Type	0 - Analog 1 - BACnet	
343		BV79	Control Loop 2 Setpoint Type	0 - Analog 1 - BACnet	
344		BV80	Control Loop 3 Setpoint Type	0 - Analog 1 - BACnet	
345		BV81	Control Loop 4 Setpoint Type	0 - Analog 1 - BACnet	
346		<b>Character String Value/ Proprietary object</b>	CS1	Room 1 Label	
347	CS2		Room 2 Label	Room label for Room 2 to be display on main window	
348	CS3		Room 3 Label	Room label for Room 3 to be display on main window	
349	CS4		Room Profile 1 Label	Label for room Profile #1	
350	CS5		Room Profile 2 Label	Label for room Profile #2	
351	CS6		Room Profile 3 Label	Label for room Profile #3	
352	CS7		Room Profile 4 Label	Label for room Profile #4	
353	CS8		Room Profile 1 Banner Text	Banner text for room Profile #1	
354	CS9		Room Profile 2 Banner Text	Banner text for room Profile #2	
355	CS10		Room Profile 3 Banner Text	Banner text for room Profile #3	
356	CS11		Room Profile 4 Banner Text	Banner text for room Profile #4	
357	CS12		Technical Support ID	Field for displaying contact information for support	
358	CS13		Audit Trail String 1	Audit trail messages	
359	CS14		Audit Trail String 2		
360	CS15		Audit Trail String 3		
361	CS16		Audit Trail String 4		
362	CS17		Audit Trail String 5		
363	CS18		Operator Password	Operator Password	
364	<b>Event Enrollment **</b>	EE1	Event enrollement 1	Event enrollement 1	
365		EE2	Event enrollement 2	Event enrollement 2	
366		EE3	Event enrollement 3	Event enrollement 3	
367		EE4	Event enrollement 4	Event enrollement 4	
368	<b>Loop</b>	L1	Control loop 1	Contains the information for control loop 1	
369		L2	Control loop 2	Contains the information for control loop 2	
370		L3	Control loop 3	Contains the information for control loop 3	
371		L4	Control loop 4	Contains the information for control loop 4	
372	<b>Multi State Input</b>	MSI1	Room 1 Pressure Alarm State	Indicates the pressure alarm state for Room 1	Alarm State List 1 - NORMAL 2 - WARNING 3 - ALARM 4 - STANDBY
373		MSI2	Room 1 Temperature Alarm State	Indicates the temperature alarm state for Room 1	
374		MSI3	Room 1 Humidity Alarm State	Indicates the humidity alarm state for Room 1	
375		MSI4	Room 1 ACH Alarm State	Indicates the ACH alarm state for Room 1	
376		MSI5	Room 1 User Defined 1 Alarm State	Indicates the user defined 1 alarm state for Room 1	
377		MSI6	Room 1 User Defined 2 Alarm State	Indicates the user defined 2 alarm state for Room 1	
378		MSI7	Room 2 Pressure Alarm State	Indicates the pressure alarm state for Room 2	
379		MSI8	Room 2 Temperature Alarm State	Indicates the temperature alarm state for Room 2	
380		MSI9	Room 2 Humidity Alarm State	Indicates the humidity alarm state for Room 2	
381		MSI10	Room 2 ACH Alarm State	Indicates the ACH alarm state for Room 2	
382		MSI11	Room 2 User Defined 1 Alarm State	Indicates the user defined 1 alarm state for Room 2	
383		MSI12	Room 2 User Defined 2 Alarm State	Indicates the user defined 2 alarm state for Room 2	
384		MSI13	Room 3 Pressure Alarm State	Indicates the pressure alarm state for Room 3	
385		MSI14	Room 3 Temperature Alarm State	Indicates the temperature alarm state for Room 3	
386		MSI15	Room 3 Humidity Alarm State	Indicates the humidity alarm state for Room 3	
387		MSI16	Room 3 ACH Alarm State	Indicates the ACH alarm state for Room 3	
388		MSI17	Room 3 User Defined 1 Alarm State	Indicates the user defined 1 alarm state for Room 3	
389		MSI18	Room 3 User Defined 2 Alarm State	Indicates the user defined 2 alarm state for Room 3	

# Master list for Setra FLEX™ supported BACnet objects

Sl. No.	Object Type	Instances	Object Name	Object description	Options
390	Multi-State Value	MV1	Room 1 Pressure Source	See option list A	Option list A
391		MV2	Room 1 Temperature Source		1 - NONE
392		MV3	Room 1 Humidity Source		2 - INT_ADC_1
393		MV4	Room 1 ACH Source		3 - INT_ADC_2
394		MV5	Room 1 User Defined 1 Source		4 - INT_ADC_3
395		MV6	Room 1 User Defined 2 Source		5 - INT_ADC_4
396		MV7	Room 2 Pressure Source		6 - EXT_ADC_1
397		MV8	Room 2 Temperature Source		7 - EXT_ADC_2
398		MV9	Room 2 Humidity Source		8 - EXT_ADC_3
399		MV10	Room 2 ACH Source		9 - EXT_ADC_4
400		MV11	Room 2 User Defined 1 Source		10 - EXT_ADC_5
401		MV12	Room 2 User Defined 2 Source		11 - EXT_ADC_6
402		MV13	Room 3 Pressure Source		12 - EXT_ADC_7
403		MV14	Room 3 Temperature Source		13 - EXT_ADC_8
404		MV15	Room 3 Humidity Source		14 - BACnet
405		MV16	Room 3 ACH Source		Option list B
406		MV17	Room 3 User Defined 1 Source	1 - ROOM Profile 1	
407		MV18	Room 3 User Defined 2 Source	2 - ROOM Profile 2	
408		MV19	Room 1 Room Profile	3 - ROOM Profile 3	
409		MV20	Room 2 Room Profile	4 - ROOM Profile 4	
410		MV21	Room 3 Room Profile	Option list C	
411		MV22	On-board Analog Output Type	See option list C	
412		MV23	I/O Module Analog Output 1 Type	See option list D	
413		MV24	I/O Module Analog Output 2 Type	1 - 0-5VDC	
414		MV25	I/O Module Analog Output 3 Type	2 - 0-10VDC	
415		MV26	I/O Module Analog Output 4 Type	3 - 4-20mA	
416		MV27	On-Board Analog Input 1 Type	See option list E	Option list D
417		MV28	On-Board Analog Input 2 Type		1 - 0-5VDC
418		MV29	On-Board Analog Input 3 Type		2 - 0-10VDC
419		MV30	On-Board Analog Input 4 Type		Option list E
420		MV31	I/O Module Input 1 Type		1 - Not Configured
421		MV32	I/O Module Input 2 Type		2 - 4-20mA
422		MV33	I/O Module Input 3 Type		3 - VDC
423		MV34	I/O Module Input 4 Type		4 - DIGITAL
424		MV35	I/O Module Input 5 Type	Option list F *	
425		MV36	I/O Module Input 6 Type	1 - Icon 1	
426		MV37	I/O Module Input 7 Type	2 - Icon 2	
427		MV38	I/O Module Input 8 Type	n - Icon n	
428		MV39	Room Profile 1 Icon	See option list F	Option list G
429		MV40	Room Profile 2 Icon		1 - BLUE
430		MV41	Room Profile 3 Icon		2 - GREEN
431		MV42	Room Profile 4 Icon		3 - YELLOW
432		MV43	Room Profile 1 Color	See option list G	4 - ORANGE
433		MV44	Room Profile 2 Color		5 - PURPLE
434		MV45	Room Profile 3 Color		6 - RED
435		MV46	Room Profile 4 Color		Option list H
436		MV47	Room Profile 1 - Control Level	See option list H	1 - Level-A
437		MV48	Room Profile 2 - Control Level		2 - Level-B
438		MV49	Room Profile 3 - Control Level		
439		MV50	Room Profile 4 - Control Level		
440		MV51	Room Profile 1 - Monitor Level		
441		MV52	Room Profile 2 - Monitor Level		
442		MV53	Room Profile 3 - Monitor Level		
443		MV54	Room Profile 4 - Monitor Level		

# Master list for Setra FLEX™ supported BACnet objects

Sl. No.	Object Type	Instances	Object Name	Object description	Options	
444		MV55	Room 1 Pressure BACnet Source Object Type	See option list J	Option list J	
445		MV56	Room 1 Temperature BACnet Source Object Type		1 - Analog Input	
446		MV57	Room 1 Humidity BACnet Source Object Type		2 - Analog Output	
447		MV58	Room 1 ACH BACnet Source Object Type		3 - Analog Value	
448		MV59	Room 1 User Defined 1 BACnet Source Object Type		See option list K	Option list K
449		MV60	Room 1 User Defined 2 BACnet Source Object Type			1 - None
450		MV61	Room 2 Pressure BACnet Source Object Type			2 - Room 1 Pressure
451		MV62	Room 2 Temperature BACnet Source Object Type			3 - Room 1 Temperature
452		MV63	Room 2 Humidity BACnet Source Object Type			4 - Room 1 Humidity
453		MV64	Room 2 ACH BACnet Source Object Type			5 - Room 1 ACH
454		MV65	Room 2 User Defined 1 BACnet Source Object Type			6 - Room 1 User Defined 1
455		MV66	Room 2 User Defined 2 BACnet Source Object Type			7 - Room 1 User Defined 2
456		MV67	Room 3 Pressure BACnet Source Object Type			8 - Room 2 Pressure
457		MV68	Room 3 Temperature BACnet Source Object Type			9 - Room 2 Temperature
458		MV69	Room 3 Humidity BACnet Source Object Type			10 - Room 2 Humidity
459		MV70	Room 3 ACH BACnet Source Object Type			11 - Room 2 ACH
460		MV71	Room 3 User Defined 1 BACnet Source Object Type			12 - Room 2 User Defined 1
461		MV72	Room 3 User Defined 2 BACnet Source Object Type		13 - Room 2 User Defined 2	
462		MV73	On-board analog output source		See option list K	14 - Room 3 Pressure
463		MV74	I/O Module analog output 1 source			15 - Room 3 Temperature
464		MV75	I/O Module analog output 2 source			16 - Room 3 Humidity
465		MV76	I/O Module analog output 3 source			17 - Room 3 ACH
466		MV77	I/O Module analog output 4 source			18 - Room 3 User Defined 1
467	MV78	On-board relay source	See option list L	19 - Room 3 User Defined 2		
468	MV79	I/O Module relay 1 source		20 - Control Loop 1		
469	MV80	I/O Module relay 2 source		21 - Control Loop 2		
470	MV81	I/O Module relay 3 source		22 - Control Loop 3		
471	MV82	I/O Module relay 4 source	See Option List M	23 - Control Loop 4		
472	MV83	Room 1 Door Source		Option list L *		
473	MV84	Room 2 Door Source		1 - None		
474	MV85	Room 3 Door Source		2 - Room 1 Door		
475	Notification Class	NC1	Notification class 1	Notification class 1	3 - Room 2 Door	
476		NC2	Notification class 2	Notification class 2	4 - Room 3 Door	
477		NC3	Notification class 3	Notification class 3	5 - Room 1 Alarm	
478		NC4	Notification class 4	Notification class 4	6 - Room 2 Alarm	
					7 - Room 3 Alarm	
					8 - Master Alarm	
					Option list M	
					1 - None	
					2 - INT_ADC_1	
					3 - INT_ADC_2	
					4 - INT_ADC_3	
					5 - INT_ADC_4	
					6 - EXT_ADC_1	
					7 - EXT_ADC_2	
					8 - EXT_ADC_3	
					9 - EXT_ADC_4	
					10 - EXT_ADC_5	
					11 - EXT_ADC_6	
					12 - EXT_ADC_7	
					13 - EXT_ADC_8	